


SERVO-i / SERVO-s Computer Interface Emulator CIE
CIE Protocol version 003
Reference Manual

CRITICAL CARE



1	INTRODUCTION	4
1.1	General information	4
1.2	Operation	5
1.3	Equipment combinations	5
2	Functional Overview.....	6
3	Compatibility.....	7
3.1	References.....	8
4	Communication - General	9
4.1	General.....	9
4.2	Typographical conventions.....	9
4.3	Definitions and Acronyms	9
4.3.1	Definitions	9
4.3.2	Date format	10
4.3.3	Common acronyms	10
4.4	The RS-232 communication settings.....	11
4.5	Signal Handshake protocol.....	11
4.6	Error handling.....	12
4.7	Performance	13
4.8	Support for different CIE Protocol versions.....	13
4.9	Channels	14
4.9.1	Channel 00-99:	14
4.9.2	Channel 100-199:	16
4.9.3	Channel 200-299:	17
4.9.4	Channel 300-399:	19
4.9.5	Switch Parameters for Channels 300 to 399:.....	22
4.9.6	Channel 400-499:	26
4.9.7	Channel 500-999:	28
5	Basic Commands	29
5.1	General.....	29
5.2	Empty command	29
5.3	Address Number AN	30
5.4	Alarm Output AO	30
5.5	Battery Check BC.....	30
5.6	Change Time Out CT	30
5.7	Define Breath DB	30
5.8	Define Curve DC.....	31
5.9	Firmware Version SV	31
5.10	Hello HO	31
5.11	Read Breath RB.....	31
5.12	Read Curve RC.....	31
5.13	Read Sampling Time RS.....	32
5.14	Read Time RT	32
5.15	Read Version RV.....	32
5.16	Change Sampling Time CS	33
5.17	Set Time ST (not supported)	33
5.18	Trend Output TO	33
5.19	Ultra Curve UC	34
5.20	Ultra Trend UT	36
6	Extended Commands.....	37
6.1	General.....	37
6.2	Empty command	38
6.3	Admit Patient ADMP	38
6.4	Discharge Patient DISP	38

6.5	Read Acquired Data RADA.....	38
6.5.1	Curve Data	38
6.5.2	Breath Data	40
6.5.3	Settings Data	40
6.5.4	Alarm Data	40
6.5.5	Alarm Data with extended output.....	40
6.5.6	Trend Data	41
6.6	Read Acquired Data Continuously RADC.....	43
6.7	Read Address Number RADN	46
6.8	Read Alarm Output RALO	46
6.9	Read Analog Input Code RAIC.....	46
6.10	Read Battery RBAT	46
6.11	Read Channel Configuration RCCO	47
6.12	Read CI Type RCTY	48
6.13	Read Data Acquisition Definition RDAD	48
6.14	Read Highest Protocol Version RHVE.....	49
6.15	Read Patient Info RPAI	49
6.16	Read Protocol Version RPVE	50
6.17	Read Serial Number RSEN	50
6.18	Read Sampling Time RSTI.....	50
6.19	Read Software Version RSWV	50
6.20	Read Text RETX	52
6.21	Read Time RTIM.....	52
6.22	Read Time out RTOU	52
6.23	Set Data Acquisition Definition SDAD.....	53
6.24	Set Protocol Version SPVE.....	53
6.25	Set Sampling Time SSMP	54
6.26	Set Time STIM (not supported).....	54
6.27	Set Time Out STOU	54
6.28	Store Text STTX	54
7	Checksum Calculation	55
7.1	General	55
7.2	Formula	55
7.3	Checksum transmission.....	55
7.4	Example.....	55
8	Revision History.....	56
8.1	Reference Manual – Revision 03	56
8.1.1	General changes – Revision 03	56
8.1.2	History table – Revision 03	56
8.2	Reference Manual – Revision 04	57
8.2.1	History table – Revision 04	57
8.3	Reference Manual – Revision 05	58
8.3.1	History table – Revision 05	58
8.4	Reference Manual – Revision 06	59
8.4.1	History table – Revision 06	59
8.5	Reference Manual – Revision 07	60
8.5.1	History table – Revision 07	60
8.6	Reference Manual – Revision 08	62
8.6.1	History table – Revision 08	62
8.7	Protocol version 003 – Reference Manual revision 09	64
8.7.1	History table – Revision 09	64

1 INTRODUCTION

1.1 General information

- The purpose of this Reference Manual is to describe the design of the SERVO-i / SERVO-s Computer Interface Emulator (CIE) Protocol version 0003, introduced with SERVO-i / SERVO-s System version 6.0. The manual provides information about commands and responses in using the SERVO-i / SERVO-s Computer Interface Emulator (CIE).
 - Updated revisions of the Reference Manual will be published when new CIE Protocol versions are released. It is recommended to use the latest version of the Reference Manual, check on www.maquet.com for updates.
 - The SERVO-i / SERVO-s Computer Interface Emulator (CIE) described herein interfaces an external equipment via an RS-232C serial interface. This specification states the requirements for the communication protocol between the CIE and an external equipment.
 - This Reference Manual is intended for programmers only.
 - Throughout this Reference Manual;
 - **SERVO-i** represents SERVO-i Ventilator System.
 - **SERVO-s** represents SERVO-s Ventilator System.
- The information in this Reference Manual is valid for both SERVO-i and SERVO-s Computer Interface Emulator (CIE) unless stated otherwise.
- The SERVO-i / SERVO-s Computer Interface Emulator is an integrated part of the SERVO-i / SERVO-s Ventilator System. In addition to the information given here, always pay attention to the information in the User's Manual.
 - The SERVO-i / SERVO-s Computer Interface Emulator must not be used as a component in a remote alarm system.
 - The SERVO-i / SERVO-s Computer Interface Emulator described herein emulates the Computer Interface (CI) of the Servo Ventilator 300/300A (SV 300) protocol, ref. [1], and the Servo Computer Module 990 (SCM 990) protocol, ref. [2], and interfaces an external equipment via an RS-232C serial interface.
 - MAQUET has no responsibility for the safe operation of the equipment if service or repair is done by a non-professional or by persons who are not employed by or authorized by MAQUET. We recommend that service be done as part of a service contract with MAQUET.
 - **Caution:** Federal law in the USA restricts this device to sale by, or on the order of a physician (or a properly licensed practitioner).


1.2 Operation

- Due to factors not controlled by MAQUET, the correctness of processed metering values obtained from the SERVO-i / SERVO-s Computer Interface Emulator cannot be guaranteed in all situations. It is therefore recommended that the data is verified against actual preset and measured values of SERVO-i / SERVO-s.
- If there should be any deviation between information shown on SERVO-i / SERVO-s and that shown by external equipments, the parameters shown on SERVO-i / SERVO-s shall be considered the primary source for information.
- In the case of external equipment not recommended by MAQUET, MAQUET disclaims all responsibility for the correctness of signals processed by such external equipment.
- Data obtained from the SERVO-i / SERVO-s Computer Interface Emulator, which has been processed in external equipments, must not be used as a substitute for therapeutic or diagnostic decisions. Such decisions can be made only by staff with medical expertise, according to established and accepted practice.

1.3 Equipment combinations

- Only components, accessories, supplies and external equipment recommended by MAQUET should be used with the system. The whole system must comply with the IEC 60601-series. Contact your local MAQUET representative for further information regarding recommended equipment. Use of any other components, accessories, supplies and external equipment may cause degraded system performance and safety.

2 Functional Overview



The information transfer between the CIE and the external equipment is performed via the serial communication link. The external equipment acts as the master and transmits commands to the CIE in order to retrieve information.

For Curve data, the desired channels, the sampling speed and the number of samples to be read by the external equipment are defined by commands. Due to memory limitation, a maximum of 4 channels can be sampled at the same time.

When a breath is completed, all applicable channels are read to the Breath parameters buffer. Once a minute a number of channel data are stored into the Breath Trend parameters buffer, calculated as filtered values over the last minute. The buffer stores trend values for the last 24 hours of operation. The channel numbers are defined by the firmware of the CIE and cannot be changed.

Setting parameters buffer is updated at every change of settings, Alarm parameters buffer is updated every 500 ms.

On command from the external equipment, the parameter values are fed to the Output buffer and clocked out via the serial port. In order to fulfill isolation requirements, the CIE uses opto couplers on the serial input and output.

3 Compatibility

About SCM 990 compatibility

The SCM 990, Firmware version 2.1 protocol (see ref. [2]) is emulated - BASIC commands.

The following items are the major differences as compared with the SCM 990 – Reference Manual:

- The minimum internal sampling period is 10 ms.
- Aux. channels are emulated.
- The SCM 990 internal battery. (Other voltage level emulated, corresponding to SV 300.)
- The EXTENDED commands. (Not present in the SCM 990.)
- More channels are trended, see further section 4.9.
- The parameter Airway flow * 10, channel 13, only gives the Airway flow, channel 00, multiplied by 10.
- The 'Read Version' command.
- Communication settings.

About SV 300 compatibility

The SV 300 CI, Version 2.0 and above communication protocol (see ref. [1]) is emulated - EXTENDED commands. The following items are the major differences as compared with the SV 300 – Reference Manual:

- Aux. channels are emulated (channels: 32 - 39, 104 - 111, 214 - 221, 237).
- Some channels are emulated and some are not supported, for further details see the section 4.9 and the ref. [1] document.
- Settings and alarm channels are not available as trends.
- In SV 300, all basic channels 0-39 are available as both curve channels and breath channels. In SERVO-i / SERVO-s, curve channels are available as breath channels but not vice versa.
- In SV 300, it is possible to read all basic trend channels 0-33. In SERVO-i / SERVO-s, only the specified trend channels are possible to read. For further details see section 4.9 and the ref. [1] document.
- The minimum internal sampling period is 10 ms.
- The commands ADMP, DISP, RADA, RADC, RADN, RAIC, RBAT, RCTY, RSWV, RV and STIM are modified in SERVO-i / SERVO-s.
- The commands RADAЕ, SDAЕ, RHVE, RPVE, SPVE and RSEN are added in SERVO-i / SERVO-s.

About SERVO-i / SERVO-s compatibility

The information in this Reference Manual is valid for both the SERVO-i and the SERVO-s Computer Interface Emulator (CIE) unless stated otherwise.

To consider when writing a CIE driver

The CIE Protocol is designed to be backwards compatible. At startup, the functionality from CIE Protocol version 001 (introduced with SERVO-i / SERVO-s System version V4.0) is available; refer to CIE Reference Manual, Revision 07.

New or modified data channels are available after selecting higher CIE Protocol versions with the command SPVE. The protocol version is selectable from CIE Protocol version 001 to highest for the current SERVO-i / SERVO-s System version, read by the RHVE command. See chapter 4.8 Support for different CIE Protocol versions.

The output from the command RSWV will be updated when a new SERVO-i / SERVO-s System SW version is released. The output from the command RHVE will be updated when a new CIE Protocol version is released.

After sending a command to CIE, wait for the response or abort the command with ESC.

3.1 References

- [1] Servo Ventilator 300/300A, Computer Interface, Firmware version 2.X, Reference Manual, Order No. 63 14 061 E380E.
- [2] Servo Computer Module 990, Firmware version 2.1, Reference Manual, Order No. 63 09 178 E357E.

4 Communication - General

4.1 General

The CIE emulates the SV 300 CI and the SCM 990 protocols and interfaces an external equipment via an RS-232C serial interface.

The information transfer between the CIE and the external equipment is performed via a serial communication line. The external equipment acts as the master and transmits commands to the CIE in order to retrieve information.

Curve data, breath data, trend data, settings data, alarm data and technical information may be retrieved from the ventilator through CIE.

4.2 Typographical conventions

When reading this manual, note that:

< >	Encloses abbreviations, numerical value, etc.
NN ₁₆	Means hexadecimal value.
[]	Encloses parameters that are not necessary to use.
{ }	Encloses the set of valid data.
...	Indicates sequence.

4.3 Definitions and Acronyms

4.3.1 Definitions

Alarm	Alarm data is alarm information generated by the ventilator. Alarms are not available as trends.
BASIC Mode	Only BASIC commands are valid, see further section 5.
Breath	Breath data changes at maximum once a breath.
Curve	Curve data changes very often and is typically used to draw real time graphs. It is sampled periodically.
Edi	Electrical activity of the diaphragm
Extended Alarm data	Alarm data that also contains information if the alarm is active, but silenced on the ventilator.
EXTENDED Mode	Only EXTENDED commands are valid, see further section 6.
NAVA	Neurally Adjusted Ventilatory Assist
NIV	Non-invasive ventilation.
Parameter	CIE command parameter, i.e. extra information needed to define the semantics of a given CIE command message. For instance, for a read command the parameter designates the data to read.
Preset cycle time	The time equal to 1/CMV freq. (BPM).
Settings	Settings data represent panel settings. Settings are not available as trends.
Technical	Technical information, e.g. module version, configuration, etc.
Trend	Trend data is calculated and stored as one value every minute.

4.3.2 Date format

Date format used by CIE:

- Year 1990–1999 is encoded as 90–99, i.e. year 99 is interpreted as 1999.
- Year 2000–2089 is encoded as 00–89, i.e. year 10 is interpreted as 2010.

The valid date range of SERVO-i / SERVO-s is 1970-01-01 – 2037-12-31.

4.3.3 Common acronyms

AD	Alarm data
BPM	Breaths per minute
BR	Breath data
BT	Breath data (as trend)
CI	Computer Interface
CIE	Computer Interface Emulator
CMV	Continuous Mandatory Ventilation
CPAP	Continuous Positive Airway Pressure
CU	Curve data
Exp time	Expiration time
Insp time	Inspiration time
N/A	Not applicable
PCB	Printed Circuit Board
PEEP	Positive End Expiratory Pressure
SCM 990	Servo Computer Module 990
SD	Settings data
SV 300	Servo Ventilator 300/300A
SV 900	Servo Ventilator 900C/D/E

4.4 The RS-232 communication settings

Baud rate:	9600
Data length:	7 or 8 bits
Stop bits:	1 or 2 bits
Parity:	Even
Data format:	ASCII or Binary (Binary format requires 8 data bits)
Handshake:	XON/XOFF

Both the Data length (7 or 8 bits) and Stop bits (1 or 2 bits) are auto-detected.

4.5 Signal Handshake protocol

The CIE enters BASIC mode at startup and when receiving the command 'Hello', HO. When CIE enters BASIC mode, all activated channels are cleared.

In BASIC Mode the CIE only recognizes the BASIC commands and the 'Read CI Type', RCTY command, which is an EXTENDED command.

In BASIC Mode when the CIE receives the command 'Read CI Type', RCTY, it will enter EXTENDED Mode. When CIE enters EXTENDED Mode, all activated channels are cleared and the selected protocol version is set to 001 (SERVO-i / SERVO-s V4.0).

In EXTENDED Mode the CIE only recognizes the EXTENDED commands and the 'Hello', HO command which is a BASIC command.

Note that all requirements regarding channels and their output in EXTENDED Mode are only applicable for the highest protocol version available.

The following control characters are used, in order to control the data flow from the CIE:

<EOT> = 04 ₁₆	End of transmission. General character to be used to define the end of an instruction or end of an ASCII response from the CIE.
<CR> = 0D ₁₆	Carriage Return character.
<LF> = 0A ₁₆	Line Feed character.
<XON> = 11 ₁₆	Issued by the external equipment to start the data flow from the CIE if the external equipment has previously stopped the data flow. (Note 1)
<XOFF> = 13 ₁₆	Issued by the external equipment to stop the data flow from the CIE. Upon reception of XOFF, CIE stops transmission as soon as possible. (Note 1)
<ESC> = 1B ₁₆	Issued by the external equipment to interrupt the data transfer from the CIE. Upon reception of ESC, CIE stops transmission and any running command, e.g. RADC, as soon as possible. Transmission is restarted upon reception of the next valid command.
<CHK>	Calculated checksum (EXTENDED mode only). The checksum calculation is defined in section 7.

Note 1: Some external equipment with automatic Xon/Xoff control may automatically remove the 11₁₆ and 13₁₆. To avoid this, it is recommended to implement Xon/Xoff control in the application

4.6 Error handling

The CIE validates input data in order to detect errors. In case of error, the CIE replies with an error message depending on the type of error and the command type, i.e. ASCII or binary.

The following error messages apply to commands with ASCII response:

Error	Error code	BASIC commands error message	EXTENDED commands error message
Not a valid command	ER10	ER10<EOT>	ER10<CHK><EOT>
Syntax error, e.g. too many or too few parameters	ER11	ER11<EOT>	ER11<CHK><EOT>
Parameter value out of range or parameter not supported by the ventilator	ER12	ER12<EOT>	ER12<CHK><EOT>
No trend values, i.e. requested start time not within trend buffer, no trend values within the time period requested, or requested trend length less than one minute	ER13	ER13<EOT> (Note 1)	ER13<CHK><EOT> (Note 1)
Trend length error, i.e. requested trend length exceeds available trend buffer	ER14	ER14<EOT> (Note 1)	ER14<CHK><EOT> (Note 1)
Trend channel not defined	ER15	ER15<EOT>	ER15<CHK><EOT>
CIE not configured	ER16	N/A	ER16<CHK><EOT>
Ventilator is in Standby mode	ER17	N/A	ER17<CHK><EOT>
Checksum error	ER18	N/A	ER18<CHK><EOT>
Buffer full	ER19	ER19<EOT>	ER19<CHK><EOT>

Note 1: Not applicable for SERVO-s of System version 1.0. No trend data is available in SERVO-s V1.0.

The following error messages apply to commands with Binary response:

Error	Error code	BASIC commands error message	EXTENDED commands error message
Not a valid command	N/A	N/A	N/A
Syntax error, e.g. too many or too few parameters	0B ₁₆	E00B7F	E00B7F<CHK>
Parameter value out of range or parameter not supported by the ventilator	0C ₁₆	E00C7F	E00C7F<CHK>
No trend values, i.e. requested start time not within trend buffer, no trend values within the time period requested or requested trend length less than one minute	0D ₁₆	E00D7F (Note 1)	E00D7F<CHK> (Note 1)
Trend length error, i.e. requested trend length exceeds available trend buffer	0E ₁₆	E00E7F (Note 1)	E00E7F<CHK> (Note 1)
Trend channel not defined	0F ₁₆	E00F7F	E00F7F<CHK>
CIE not configured	10 ₁₆	N/A	E0107F<CHK>
Ventilator is in Standby mode	11 ₁₆	N/A	E0117F<CHK>
Checksum error	N/A	N/A	N/A
Buffer full	13 ₁₆	E0137F	E0137F<CHK>

Note 1: Not applicable for SERVO-s of System version 1.0. No trend data is available in SERVO-s V1.0.

Note that since all CIE command messages are ASCII messages, the error 'Not a valid command' is always returned as an ASCII response message. This is the reason why the error 'Not a valid command' is not applicable as a binary response message.

Note that 'Checksum error' is always returned as an ASCII response message since it is not possible to determine what command generated the error.

If it is not possible to calculate or retrieve data designated by a command parameter within the CIE, a 'Missing value' is transferred, which is 9999 for ASCII and 7EFF₁₆ for Binary.

4.7 Performance

The CIE needs to receive any character within set time-out; otherwise the previous characters are ignored.

See command CT, chapter 5.6, command RTOU, chapter 6.22 and command STOU, chapter 6.27 for more information.

The CIE sends the first character of the response to all commands within 500 ms, unless otherwise stated in the description of each specific command.

4.8 Support for different CIE Protocol versions

The CIE provides a mechanism for selecting between different protocol versions in EXTENDED Mode.

The following commands are used:

- Read Highest Protocol Version, RHVE: Requests information about the highest available CIE Protocol version for the current SERVO-i / SERVO-s System version.
- Read Protocol Version, RPVE: Requests information about the CIE Protocol version currently in use.
- Set Protocol Version, SPVE: Configures CIE to use a specific Protocol version.

The lowest selectable CIE Protocol version shall be 001. This protocol version will be selected when changing from BASIC Mode to EXTENDED Mode.

The difference between protocol versions are that:

- Existing channels can be deleted.
- New channels can be added.
- Configuration, or switch parameters, for existing channels can be changed.
- New commands can be added.

4.9 Channels

Each parameter corresponds to a channel number. The following tables define channels and corresponding parameter:

Channels 00 - 99 are reserved for the BASIC protocol.

Channels 100 - 999 are reserved for the EXTENDED protocol. The trend channel numbers are in this area equivalent to channel No.

4.9.1 Channel 00-99:

Basic SCM 990 protocol channels according to ref. doc. [2].

CIE returns the raw value of a basic channel, which is graded in the unit [4.883mV]. The raw value 2048 corresponds to 0V. Thus, the value graded in engineering unit is calculated according to the following formula:

$$\langle \text{value} \rangle = ((\langle \text{raw_value} \rangle - 2048) * 4.883) / \langle \text{scale_factor} \rangle$$

Note that the engineering unit is given by the scale factor of each channel, e.g. the channel airway flow has the scale factor 5000mV/l/s, which gives the engineering unit [l/s].

All curve channels are available as breath channels as well, but not vice versa.

All curve data are based on internal transducer data (even with the SERVO-i option Y-piece measurement active) unless stated as Y-piece curves. Most breath data are based on Y-piece data when Y-piece measurement active.

CIE supports basic channels according to the following table:

Ch No	Trend No	Parameter Name	Scale Factor
0		Airway Flow (curve)	5000mV/l/s
1	20	Insp. Tidal vol. (breath)	5000mV/l
2		Airway Pressure Insp (curve)	50mV/cm H ₂ O
3	21	Exp. Tidal vol. (breath)	5000mV/l
4	0	O ₂ -concentration (breath)	50mV/%
5	22	Baro. Pressure (breath) (Note 3)	4883mV/Bar
6	33	Aux_Code (breath) (emulated = 2303)	4.883 mV/bit
7	1	Pause Pressure (breath)	50mV/cm H ₂ O
8	2	Resp. rate calc (breath)	50mV/breaths/min
9	3	Peak pressure (breath)	50mV/cm H ₂ O
10	4	Exp. minute vol. (breath)	200mV/l/min
11	23	Mean airway pressure (breath)	50mV/cm H ₂ O
12		Airway Pressure Exp (curve)	50mV/cm H ₂ O
13		Airway flow *10 (curve) (Note 4)	50000mV/l/s
14		Not Used (breath) (emulated = 2048)	
15		CI Battery Voltage (curve) (emulated = 2826) (Note 2)	1000mV/V
16		Not Used (breath) (emulated = 2048)	
17		CO ₂ concentration (curve) (Note 1)	1000mV/%CO ₂
18	7	Ineff tidal volume (breath) (emulated = 2048)	
19	8	Eff tidal volume (breath) (emulated = 2048)	
20	9	CO ₂ tidal prod. (breath) (Note 1)	100mV/ml CO ₂

21	10	End tidal CO ₂ conc. (breath) (Note 1)	1000mV/%CO ₂
22	11	CO ₂ minute prod. (breath) (Note 1)	10mV/ml CO ₂ /min
23	12	Eff. Ventilation (breath) (emulated = 2048)	
24	13	Tidal volume (breath) (emulated = 2048)	
25		Airway pressure (breath) (emulated = 2048)	
26	15	Exp. Resistance (breath)	20 mV/cm H ₂ O/l/s
27	16	Static Compliance (breath)	10 mV/ml/cm H ₂ O
28	17	End exp. Flow (breath)	1000 mV/l/s
29	18	End exp. pressure (breath)	100mV/cm H ₂ O
30	19	End exp. lung pressure (breath) (emulated = 2048)	
31	24	Insp. Resistance (breath)	20 mV/cm H ₂ O/l/s
32	25	AUX Channel 1 (curve) (emulated = 2048)	
33	26	AUX Channel 2 (curve) (emulated = 2048)	
34	27	AUX Channel 3 (curve) (emulated = 2048)	
35	28	AUX Channel 4 (curve) (emulated = 2048)	
36	29	AUX Channel 5 (curve) (emulated = 2048)	
37	30	AUX Channel 6 (curve) (emulated = 2048)	
38	31	AUX Channel 7 (curve) (emulated = 2048)	
39	32	AUX Channel 8 (curve) (emulated = 2048)	
40 - 99		Not Used	

Note 1: Not applicable for SERVO-s.

Note 2: The CI battery voltage is emulated since CIE has no battery of its own. CIE uses the Monitoring PCB battery, which is managed and supervised by the Monitoring subsystem.

Note 3: Channel 5 is not used in the SCM 990.

Note 4: Min. value for CIE output is -0.2 l/s. Output for lower actual values will be set to -0.2 l/s.

4.9.2 Channel 100-199:

Extended channels used for real-time curves. The configuration, i.e. actual scale factors and the voltage ranges, is received via the command Read Channel Configuration (RCCO). For more information about the configuration, see the description of the command RCCO.

All curve data are based on internal transducer data unless specified as Y-piece curves. When the SERVO-i option Y-piece measurement is active, data from internal transducers may differ from those presented on the User Interface. Also note that since this protocol uses one phase-flag for all curves, and Y-piece curve data are delayed 50 ms compared to internal transducer curve data, the phase-information for Y-piece curve data will be off by 50 ms.

CIE supports extended curve channels according to the following table:

Ch No	Parameter Name	Configuration (gain, offset, unit, type)
100	Airway Flow	+2713E-004, +3333E+000, 02, CU
101	Airway pressure (I)	+6510E-005, +1333E-001, 04, CU
102	Airway pressure (E)	+6510E-005, +1333E-001, 04, CU
103	CO ₂ concentration (%) (Note 1)	+1000E-004, +0000E+000, 07, CU
104	AUX Channel 1 (emulated = 2048)	+4883E-003, +1000E+001, 13, CU
105	AUX Channel 2 (emulated = 2048)	+4883E-003, +1000E+001, 13, CU
106	AUX Channel 3 (emulated = 2048)	+4883E-003, +1000E+001, 13, CU
107	AUX Channel 4 (emulated = 2048)	+4883E-003, +1000E+001, 13, CU
108	AUX Channel 5 (emulated = 2048)	+4883E-003, +1000E+001, 13, CU
109	AUX Channel 6 (emulated = 2048)	+4883E-003, +1000E+001, 13, CU
110	AUX Channel 7 (emulated = 2048)	+4883E-003, +1000E+001, 13, CU
111	AUX Channel 8 (emulated = 2048)	+4883E-003, +1000E+001, 13, CU
112	CI Battery Voltage (emulated = 2826)	+4883E-003, +1000E+001, 13, CU
113	Airway pressure	+6510E-005, +1333E-001, 04, CU
114	Volume	+4000E-004, +0000E+000, 01, CU
115	Y-piece Pressure (Note 1)	+6510E-005, +1333E-001, 04, CU
116	Y-piece Flow (Note 1)	+2713E-004, +3333E+000, 02, CU
117	Y-piece Volume (Note 1)	+4000E-004, +0000E+000, 01, CU
118	Edi (Note 1)	+2000E-005, +0000E+000, 19, CU
119	CO ₂ concentration (mmHg) (Note 1)	+1000E-004, +0000E+000, 10, CU
120 - 199	Not Used	

Note 1: Not applicable for SERVO-s.

4.9.3 Channel 200-299:

Extended channels used for breath data. The configuration, i.e. actual scale factors and the voltage ranges, is received via the command Read Channel Configuration (RCCO). For more information about the configuration see the description of the command RCCO.

Most breath data will be based on Y-piece data when the SERVO-i option Y-piece measurement is active.

CIE supports extended breath channels according to the following table:

Ch No	Parameter Name	Configuration (gain, offset, unit, type)
200	Measured breath frequency	+1000E-004, +0000E+000, 06, BT
201	Exp. tidal volume	+1000E-003, +0000E+000, 01, BT
202	Insp. Tidal volume	+1000E-003, +0000E+000, 01, BT
203	Insp. Minute volume	+1000E-004, +0000E+000, 08, BT
204	Exp. minute volume	+1000E-004, +0000E+000, 08, BT
205	Peak pressure	+1000E-004, +0000E+000, 04, BT
206	Mean airway pressure	+1000E-004, +0000E+000, 04, BT
207	Pause pressure	+1000E-004, +0000E+000, 04, BT
208	End exp. pressure	+1000E-004, +0000E+000, 04, BT
209	O ₂ concentration	+1000E-004, +0000E+000, 07, BT
210	Barometric pressure	+1000E-003, +0000E+000, 12, BT
211	Gas supply pressure, Air	+1000E-001, +0000E+000, 12, BT
212	Gas supply pressure, O ₂	+1000E-001, +0000E+000, 12, BT
213	Gas supply pressure, Optional (emulated = 0)	+1000E-001, +0000E+000, 12, BT
214	AUX Channel 1 (emulated = 2048)	+4883E-003, +1000E+001, 13, BT
215	AUX Channel 2 (emulated = 2048)	+4883E-003, +1000E+001, 13, BT
216	AUX Channel 3 (emulated = 2048)	+4883E-003, +1000E+001, 13, BT
217	AUX Channel 4 (emulated = 2048)	+4883E-003, +1000E+001, 13, BT
218	AUX Channel 5 (emulated = 2048)	+4883E-003, +1000E+001, 13, BT
219	AUX Channel 6 (emulated = 2048)	+4883E-003, +1000E+001, 13, BT
220	AUX Channel 7 (emulated = 2048)	+4883E-003, +1000E+001, 13, BT
221	AUX Channel 8 (emulated = 2048)	+4883E-003, +1000E+001, 13, BT
222	Ineff. tidal volume (Note 2)	
223	Eff. tidal volume (Note 2)	
224	CO ₂ tidal production (Note 1)	+1000E-004, +0000E+000, 01, BT
225	End tidal CO ₂ concentration (%) (Note 1)	+1000E-004, +0000E+000, 07, BT
226	CO ₂ minute production (Note 1)	+1000E-003, +0000E+000, 03, BT
227	Eff. ventilation (Note 2)	
228	Barometric Pressure 2 nd (emulated = invalid = 7EFF ₁₆)	+1000E-003, +0000E+000, 12, BT
229	Not Used	

230	Not Used	
231	Exp. resistance	+1588E-004, +1000E-001, 09, BT
232	Static Compliance	+4976E-004, +2000E+000, 05, BT
233	End exp. Flow	+7100E-006, +3500E-002, 15, BT
234	Not Used	
235	Not Used	
236	Insp. Resistance	+4000E-004, +0000E+000, 09, BT
237	Aux_Code (emulated = 255)	-, -, -, BT
238	I:E Ratio (Note 3)	+1000E-005, +0000E+000, --, BT
239	Ti (Insufflation time)	+3300E-006, +0000E+000, 14, BR
240	C dyn i in Open Lung Tool	+5000E-004, +0000E+000, 05, BR
241	Dynamic Characteristics	+4976E-004, +2000E-001, 05, BT
242	NIV, Leakage fraction	+1310E-005, +0000E+000, 07, BT
243	Elastance	+1000E-004, +0000E+000, 16, BT
244	Ti/Ttot	+1100E-007, +0000E+000, --, BT
245	Total PEEP	+6510E-005, +1333E-001, 04, BT
246	Shallow Breathing Index (SBI) (Note 4)	+1000E-004, +0000E+000, --, BT
247	Spontaneous Breath frequency	+1000E-004, +0000E+000, 06, BT
248	Mve spont	+1000E-004, +0000E+000, 08, BT
249	MVespont/Mve in Bivent	+1100E-007, +0000E+000, --, BR
250	Time constant	+3300E-006, +0000E+000, 14, BT
251	Work of Breathing, Ventilator	+1000E-005, +0000E+000, 18, BT
252	Work of Breathing, Patient	+1000E-005, +0000E+000, 18, BT
253	CPAP (Note 1)	+1000E-004, +0000E+000, 04, BT
254	P0.1	+6510E-005, +1333E-001, 04, BT
255	Edi peak (Note 1)	+2000E-005, +0000E+000, 19, BT
256	Edi min (Note 1)	+2000E-005, +0000E+000, 19, BT
257	% Edi trigger in NAVA (Note 1)	+1310E-005, +0000E+000, 07, BR
258	% Edi cycle off in NAVA (Note 1)	+1310E-005, +0000E+000, 07, BR
259	Shallow Breathing Index (SBI)	+1000E-003, +0000E+000, 22, BT
260	End tidal CO ₂ concentration (mmHg) (Note 1)	+1000E-004, +0000E+000, 10, BT
261	Stress Index (Note 1)	+1000E-006, +0000E+000, --, BT
262	Remaining Nebulization time (Note 1)	+1000E-004, +0000E+000, 23, BR
263 –299	Not Used	

Note 1: Not applicable for SERVO-s.

Note 2: Not supported.

Note 3: CIE sends I:E Ratio in the format “value:1”. This format is also used by the SERVO-i / SERVO-s User Interface as long as “value” ≥ 1 . Example, CIE value 2.0 is displayed as 2.0:1. With a “value” < 1 the I:E Ratio is displayed in the format “1:1/value”. Example, CIE value 0.5 is displayed as 1:2.0.

Note 4: Obsolete but supported for backward compatibility. Use channel 259 instead.

4.9.4 Channel 300-399:

Extended channels used for settings. The configuration, i.e. actual scale factors and the voltage ranges, are received via the command Read Channel Configuration (RCCO). For more information about the configuration see the description of the command RCCO.

CIE supports extended settings channels according to the following table:

Ch No	Parameter Name	Configuration (gain, offset, unit, type)
300	CMV Frequency, Set	+1000E-004, +0000E+000, 06, SD
301	Insp. Time %, Set	+1000E-004, +0000E+000, 07, SD
302	Pause time %, Set	+1000E-004, +0000E+000, 07, SD
303	SIMV Frequency, Set	+1000E-004, +0000E+000, 06, SD
304	Insp. Rise time %, Set	+1000E-004, +0000E+000, 07, SD
305	Minute Volume, Set	+1000E-005, +0000E+000, 08, SD
306	Pressure Control Level above PEEP, Set	+1000E-004, +0000E+000, 04, SD
307	Pressure Support Level above PEEP, Set	+1000E-004, +0000E+000, 04, SD
308	PEEP, Set	+1000E-004, +0000E+000, 04, SD
309	Patient range selection, Set	-, -, -, SD (Note 3)
310	Ventilation Mode, Set	-, -, -, SD (Note 3)
311	Insp./Exp. Pause Hold, Oxygen Breaths/Start Breaths	-, -, -, SD (Note 3)
312	CPAP, Set (Note 1)	+1000E-004, +0000E+000, 04, SD
313	Exp. minute vol. Upper alarm limit, Set (Note 4)	+1000E-004, +0000E+000, 08, SD
314	Exp. minute vol. Lower alarm limit , Set (Note 4)	+1000E-004, +0000E+000, 08, SD
315	Upper pressure limit, Set	+1000E-003, +0000E+000, 04, SD
316	EtCO ₂ concentration Upper alarm limit, Set (%) (Note 1)	+1000E-005, +0000E+000, 07, SD
317	EtCO ₂ concentration Lower alarm limit, Set (%) (Note 1)	+1000E-005, +0000E+000, 07, SD
318	O ₂ concentration Upper alarm limit	+1000E-004, +0000E+000, 07, SD
319	O ₂ concentration Lower alarm limit	+1000E-004, +0000E+000, 07, SD
320	Not Used	
321	Not Used	
322	Alarm mute/pre-mute Status	-, -, -, SD (Note 3)
323	O ₂ concentration, Set	+1000E-004, +0000E+000, 07, SD
324	Valve slot 1, binary code (emulated = 1)	-, -, -, SD
325	Valve slot 2, binary code (emulated = 2)	-, -, -, SD

326	Valve slot 3, binary code (emulated = 63)	-, -, -, SD
327	Trigger sensitivity level below PEEP, Set	-1000E-004, +0000E+000, 04, SD
328	Trigger sensitivity level above PEEP, Set	+1000E-004, +0000E+000, --, SD
329	Language switch	-, -, -, SD (Note 3)
330	Displayed CO ₂ Unit (Note 1)	-, -, -, SD (Note 3)
331	CO ₂ Mode (Note 2)	
332	CO ₂ Execution Mode (Note 2)	
333	I:E Ratio, Set (Note 5)	+1000E-005, +0000E+000, --, SD
334	Tidal volume, Set	+1000E-003, +0000E+000, 01, SD
335	Backup RR, Set	+1000E-004, +0000E+000, 06, SD
336	Backup Ti in Seconds, Set	+1000E-005, +0000E+000, 14, SD
337	NIV Program Status	-, -, -, SD (Note 3)
338	High-pressure level in BIVENT, Set	+1000E-004, +0000E+000, 04, SD
339	High pressure level time in BIVENT, Set	+1000E-005, +0000E+000, 14, SD
340	Low pressure level, PEEP, time in BIVENT, Set	+1000E-005, +0000E+000, 14, SD
341	Pressure Support level above Phigh in BIVENT, Set	+1000E-004, +0000E+000, 04, SD
342	Pressure Support level above PEEP in BIVENT, Set	+1000E-004, +0000E+000, 04, SD
343	Insp. Time in Seconds, Set	+1000E-005, +0000E+000, 14, SD
344	Pause Time in Seconds, Set	+1000E-005, +0000E+000, 14, SD
345	Insp. Rise time, in Seconds, Set	+1000E-005, +0000E+000, 14, SD
346	SIMV Breath duration, Set	+1000E-005, +0000E+000, 14, SD
347	Back-up Pressure Level Above PEEP, Set	+1000E-004, +0000E+000, 04, SD
348	Insp. flow, Set	+1000E-006, +0000E+000, 15, SD
349	Suction support Status	-, -, -, SD (Note 3)
350	Cycle off Fraction Level, Set	+1000E-005, +0000E+000, 07, SD
351	Circuit compliance compensation Status	-, -, -, SD (Note 3)
352	Trigger timeout in Automode	+1000E-005, +0000E+000, 14, SD
353	Breath frequency Upper alarm limit, Set	+1000E-004, +0000E+000, 06, SD
354	Breath frequency Lower alarm limit, Set	+1000E-004, +0000E+000, 06, SD
355	Apnea alarm time limit, Set (Note 6)	+1000E-004, +0000E+000, 14, SD
356	PEEP Lower alarm limit, Set	+1000E-004, +0000E+000, 04, SD
357	PEEP Upper alarm limit, Set	+1000E-004, +0000E+000, 04, SD
358	CPAP Upper alarm limit, Set (Note 1)	+1000E-004, +0000E+000, 04, SD
359	CPAP Lower alarm limit, Set (Note 1)	+1000E-004, +0000E+000, 04, SD
360	Y-piece measurement status (Note 1)	-, -, -, SD (Note 3)
361	Edi trigger (Note 1)	+2000E-006, +0000E+000, 19, SD

362	NAVA level (Note 1)	+3000E-006, +0000E+000, 21, SD
363	Gas Type Setting (Note 1)	-, -, -, SD (Note 3)
364	Exp. minute vol. Upper alarm limit, Set	+1000E-005, +0000E+000, 08, SD
365	Exp. minute vol. Lower alarm limit, Set	+1000E-005, +0000E+000, 08, SD
366	EtCO ₂ concentration Upper alarm limit, Set (mmHg) (Note 1)	+1000E-004, +0000E+000, 10, SD
367	EtCO ₂ concentration Lower alarm limit, Set (mmHg) (Note 1)	+1000E-004, +0000E+000, 10, SD
368	Backup Tidal Volume, Set	+1000E-003, +0000E+000, 01, SD
369	Backup I:E Ratio, Set (Note 5)	+1000E-005, +0000E+000, --, SD
370	Apnea audio delay, Set	+1000E-004, +0000E+000, 14, SD
371	Leakage fraction too high alarm, Set (Note 1)	-, -, -, SD (Note 3)
372	Nebulization mode, Set (Note 1)	-, -, -, SD
373	Nebulization time, Set (Note 1)	+1000E-004, +0000E+000, 23, SD
374–399	Not Used	

Note 1: Not applicable for SERVO-s.

Note 2: Not supported.

Note 3: See 4.9.5 Switch Parameters for channels No. 300 to 399.

Note 4: Obsolete but supported for backward compatibility. Use channels 364/365 instead.

Note 5: CIE sends I:E Ratio in the format “value:1”. This format is also used by the SERVO-i / SERVO-s User Interface as long as “value” >= 1. Example, CIE value 2.0 is displayed as 2.0:1. With a “value” < 1 the I:E Ratio is displayed in the format “1:1/value”. Example, CIE value 0.5 is displayed as 1:2.0.

Note 6: Apnea alarm time limit value = 46 → Apnea alarm (part of Ch 412, Apnea alarm/Backup ventilation) disabled.

4.9.5 Switch Parameters for Channels 300 to 399:

Ch No	Switch Parameters
309	Patient range selection, Set Value: 1 = Neonate 2 = Adult 3 = Pediatric (Not supported)
310	Ventilation Mode, Set Value when "automode" is OFF: 1 = Value not used 2 = Pressure Control 3 = Volume Control 4 = Pressure Reg. Volume Control 5 = Volume Support 6 = SIMV (Vol. Contr.) + Pressure Support 7 = SIMV (Press. Contr.) + Pressure Support 8 = Pressure Support / CPAP 9 = Ventilation mode not supported by CIE 10 = SIMV (Pressure Reg. Volume Control) + Pressure Support 11 = Bivent 12 = Pressure Control in NIV 13 = Pressure Support / CPAP in NIV 14 = Nasal CPAP 15 = NAVA 16 = Value not used 17 = NIV NAVA Value when "automode" is ON: 18 = Pressure Control, patient does not trigger the ventilator 19 = Volume Control, patient does not trigger the ventilator 20 = Pressure Reg. Volume Control, patient does not trigger the ventilator 21 = Pressure Support / CPAP (switches to mode 18 if the patient does not trigger the ventilator) 22 = Volume Support (switches to mode 19 if the patient does not trigger the ventilator) 23 = Volume Support (switches to mode 20 if the patient does not trigger the ventilator)

311	Insp./Exp Pause Hold, Oxygen Breaths/Start Breaths Combined channel. Output value is the sum of all active functions. Example: 5 = Oxygen breaths and Insp. Pause hold. Value: <table><tr><td>0</td><td>=</td><td>Normal state, no active function</td></tr><tr><td>1</td><td>=</td><td>Insp. Pause hold</td></tr><tr><td>2</td><td>=</td><td>Exp. Pause hold</td></tr><tr><td>4</td><td>=</td><td>Oxygen breaths</td></tr><tr><td>8</td><td>=</td><td>Start breath</td></tr></table>	0	=	Normal state, no active function	1	=	Insp. Pause hold	2	=	Exp. Pause hold	4	=	Oxygen breaths	8	=	Start breath																																																
0	=	Normal state, no active function																																																														
1	=	Insp. Pause hold																																																														
2	=	Exp. Pause hold																																																														
4	=	Oxygen breaths																																																														
8	=	Start breath																																																														
322	Alarm mute/pre-mute Status Value: <table><tr><td>8</td><td>=</td><td>Normal state</td></tr><tr><td>10</td><td>=</td><td>Alarm muted/pre-muted</td></tr></table>	8	=	Normal state	10	=	Alarm muted/pre-muted																																																									
8	=	Normal state																																																														
10	=	Alarm muted/pre-muted																																																														
329	Language Switch Value: <table><tr><td>0</td><td>=</td><td>English</td></tr><tr><td>1</td><td>=</td><td>Swedish</td></tr><tr><td>2</td><td>=</td><td>German</td></tr><tr><td>3</td><td>=</td><td>French</td></tr><tr><td>4</td><td>=</td><td>Italian</td></tr><tr><td>5</td><td>=</td><td>Spanish</td></tr><tr><td>6</td><td>=</td><td>Japanese</td></tr><tr><td>7</td><td>=</td><td>Other language</td></tr><tr><td>8</td><td>=</td><td>Dutch</td></tr><tr><td>9</td><td>=</td><td>Portuguese</td></tr><tr><td>10</td><td>=</td><td>Danish</td></tr><tr><td>11</td><td>=</td><td>Turkish</td></tr><tr><td>12</td><td>=</td><td>Greek</td></tr><tr><td>13</td><td>=</td><td>Chinese</td></tr><tr><td>14</td><td>=</td><td>Russian</td></tr><tr><td>15</td><td>=</td><td>Polish</td></tr><tr><td>16</td><td>=</td><td>Hungarian</td></tr><tr><td>17</td><td>=</td><td>Czech</td></tr><tr><td>18</td><td>=</td><td>Finnish</td></tr><tr><td>19</td><td>=</td><td>Norwegian</td></tr><tr><td>20</td><td>=</td><td>Slovak</td></tr></table> In SV 300, value 0-15 is used for language and barometer display unit.	0	=	English	1	=	Swedish	2	=	German	3	=	French	4	=	Italian	5	=	Spanish	6	=	Japanese	7	=	Other language	8	=	Dutch	9	=	Portuguese	10	=	Danish	11	=	Turkish	12	=	Greek	13	=	Chinese	14	=	Russian	15	=	Polish	16	=	Hungarian	17	=	Czech	18	=	Finnish	19	=	Norwegian	20	=	Slovak
0	=	English																																																														
1	=	Swedish																																																														
2	=	German																																																														
3	=	French																																																														
4	=	Italian																																																														
5	=	Spanish																																																														
6	=	Japanese																																																														
7	=	Other language																																																														
8	=	Dutch																																																														
9	=	Portuguese																																																														
10	=	Danish																																																														
11	=	Turkish																																																														
12	=	Greek																																																														
13	=	Chinese																																																														
14	=	Russian																																																														
15	=	Polish																																																														
16	=	Hungarian																																																														
17	=	Czech																																																														
18	=	Finnish																																																														
19	=	Norwegian																																																														
20	=	Slovak																																																														

330	Displayed CO₂ Unit Value: 1 = % 2 = kPa (Note 1) 4 = mmHg (Note 2)
337	NIV Program Status Value: 0 = Undefined Status 1 = Waiting position 2 = Ventilation 3 = Disconnected
349	Suction Support Status Value: 0 = Undefined Status 1 = Normal ventilation 2 = Waiting for disconnect 3 = Disconnected 4 = Post oxygenation
351	Circuit compliance compensation Status Value: 1 = OFF 2 = ON
360	Y-piece Measurement Status Value: 1 = Inactive 2 = Active
363	Gas Type Setting Value: 0 = Undefined Gas Type 1 = Heliox 2 = Air

371	Leakage fraction too high alarm, Set Value: 1 = Alarm OFF 2 = Alarm ON
372	Nebulization mode, Set Value: 1 = OFF 2 = Intermittent 3 = Continuous

Note 1: The following formula is used to convert from % to kPa:

$$\frac{\text{Value [\%]} \times \text{Barometric Pressure [mbar]}}{1000}$$

Barometric Pressure can be reached via channel 210.

Note 2: The following formula is used to convert from % to mmHg:

$$\frac{760 \text{ [mmHg]}}{1013 \text{ [mbar]}} \times \text{Barometric Pressure [mbar]} \times \frac{\text{Value [\%]}}{100}$$

4.9.6 Channel 400-499:

Extended channels used for alarms. The configuration, i.e. actual scale factors and the voltage ranges, are received via the command Read Channel Configuration (RCCO). For more information about the configuration, see the description of the command RCCO.

CIE supports alarm channels according to the following table:

Ch No	Parameter Name
400	O ₂ conc. too high – alarm
401	O ₂ conc. too low – alarm
402	EtCO ₂ conc. too high – alarm (Note 1)
403	EtCO ₂ conc. too low – alarm (Note 1)
404	Breathing system μ P Module error – alarm (emulated = 0)
405	Inspiratory control μ P Module error – alarm (emulated = 0)
406	Panel Interface μ P Module error – alarm (emulated = 0)
407	Exp. flow & CO ₂ linearization μ P Module error – alarm (emulated = 0) (Note 1)
408	Monitoring System μ P Module error – alarm (emulated = 0)
409	Computer Interface Emulator technical error – alarm (emulated = 0)
410	Airway pressure alarm Upper pressure limit exceeded – alarm
411	Exp. minute volume – alarm One or more of following alarms: Exp. minute volume too high Exp. minute volume too low
412	Apnea alarm/Backup ventilation One or more of following alarms: Apnea No Patient Effort No Consistent Patient Effort Check Catheter position – RR and HR coupling Check Catheter position – Edi Invalid
413	Gas supply alarm
414	Battery alarm One or more of following alarms: Limited battery capacity No battery capacity
415	Not Used
416	Power Failure – alarm One or more of following alarms: -12V too low/high 12V too low/high 24V too low/high
417	Mains Failure – alarm
418	O ₂ potentiometer error – alarm (emulated = 0)
419	CMV potentiometer error – alarm (emulated = 0)

420	Range Switch error – alarm (emulated = 0)
421	Mode Switch error – alarm (emulated = 0)
422	Barometer error – alarm One or more of following alarms: Baro. Press. too high Baro. Press. too low
423	High continuous pressure – alarm
424	Overrange – alarm One or more of following alarms: Insp. Tidal volume overrange Insp. Flow overrange
425	O ₂ cell disconnect – alarm
426	Computer Interface Emulator Internal communication failure – alarm One or more of following alarms: Panel/Breathing/ExpFlowMtr disconnect Panel/Breathing/ExpFlowMtr connect timeout
427	Computer Interface Emulator hardware error – alarm (emulated = 0)
428	Alarm buff (emulated = 0)
429	CI Battery Voltage – alarm (emulated = 0)
430	Time in waiting position exceeds 2 min
431	No Patient Effort
432	Leakage out of range
433	Check tubing
434	Regulation pressure limited
435	Breath frequency High
436	Breath frequency Low
437	PEEP Low
438	PEEP High
439	CPAP High (Note 1)
440	CPAP Low (Note 1)
441	Pneumatic-Edi out of synch (Note 1)
442	Edi activity low (Note 1)
443	No Edi signal detected (Note 1)
444	Unsuccessful manual gas change alarm (Note 1)
445	Exp. Minute volume too high – alarm
446	Exp. Minute volume too low – alarm
447	Check Heliox adapter (Note 1)
448	Unreliable Edi signal (Note 1)
449	Check Catheter position – Edi Invalid (Note 1)
450	Check Catheter position – RR and HR coupling (Note 1)

451	No Consistent Patient Effort
452	Leakage fraction too high (Note 1)
453–497	Not Used
498	High Priority Alarm
499	Computer Interface Emulator Summary Alarm

Note 1: Not applicable for SERVO-s.

The data output of the alarm channels is configurable with the command SDADA, or SDADE (alarm channels with extended output).

Alarm data output without any alarm channels configured:

Alarm status	Readout command			
	RALO	RADAA (Note 1)	RADAE (Note 1)	RADC (Note 2)
No alarm	0	ER16	ER16	10 ₁₆
Alarm active	1	ER16	ER16	10 ₁₆
Alarm active but silenced	1	ER16	ER16	10 ₁₆

Note 1: ASCII coded error message ER16, CIE not configured.

Note 2 Binary coded error message E0107F16, CIE not configured.

Alarm data output when configured with SDADA:

Alarm status	Readout command			
	RALO	RADAA	RADAE Note 1	RADC
No alarm	0	0	ER16	00 ₁₆
Alarm active	1	1	ER16	FF ₁₆
Alarm active but silenced	1	1	ER16	FF ₁₆

Note 1: ASCII coded error message ER16, CIE not configured.

Alarm data output when configured with SDADE:

Alarm status	Readout command			
	RALO	RADAA Note 1	RADAE	RADC
No alarm	0	ER16	0	00 ₁₆
Alarm active	1	ER16	1	01 ₁₆
Alarm active but silenced	2	ER16	2	02 ₁₆

Note 1: ASCII coded error message ER16, CIE not configured.

4.9.7 Channel 500-999:

Extended channels not used.

500-999	Not Used
---------	----------

5 Basic Commands

5.1 General

The BASIC commands below are according to the SCM 990, Firmware version 2.0 protocol, see ref. [2].

Equipment administration commands:

Empty command	The empty command can be used for connection check.
Address Number, AN	Reads the address number of the ventilator (emulated).
Battery Check, BC	Reads the internal battery voltage (emulated).
Change Time Out, CT	Defines the command timeout.
Firmware Version, SV	Reads the firmware version.
Hello, HO	General call from the external equipment to the CIE to check the connection.
Read Time, RT	Reads the Real Time Clock.
Read Version, RV	Reads the version of the ventilator.
Set Time, ST	Sets the Real Time Clock (not supported).

Data acquisition commands:

Define Breath, DB	Defines which channels to be read by the instruction Read Breath.
Read Breath, RB	Reads the channels defined by the command Define Breath.
Change Sampling Time, CS	Sets the sampling time in milliseconds.
Read Sampling Time, RS	Reads the sampling time in milliseconds.
Define Curve, DC	Defines which channels to be read by the instruction Read Curve or Ultra Curve.
Read Curve, RC	Reads the channels defined by the command Define Curve.
Ultra Curve, UC	Reads the values, in compressed binary format, of the channels defined by the command Define Curve.
Alarm Output, AO	Requests alarm status.
Trend Output, TO	Reads one of the trend channels from the trend memory.
Ultra Trend, UT	Reads one of the trend channels from the trend memory (compressed binary).

5.2 Empty command

CIE responds to the empty command in basic mode.

Input syntax:	<EOT>
Output syntax:	*<EOT>

5.3 Address Number AN

The CIE returns the address number of the SERVO-i / SERVO-s Ventilator unit (emulated).

Input syntax: AN<EOT>
 Output syntax: <n><EOT>
 Emulated Output: 00<EOT>
 Parameters: <n> = 00-99

5.4 Alarm Output AO

The CIE returns the summary alarm status.

Input syntax: AO<EOT>
 Output syntax: <value><EOT>
 Parameters: <value> = {0 (no alarm), 1 (alarm)}

When SERVO-i / SERVO-s is in standby mode this command returns ER10, i.e. it is not a valid command in standby mode.

5.5 Battery Check BC

The CIE returns the internal battery voltage.

Input syntax: BC<EOT>
 Output syntax: <value><EOT>
 Emulated Output: 380<EOT>
 Parameters: <value> = 000-999 (steps of 10 mV)

Since CIE has no battery of its own within SERVO-i / SERVO-s, the emulated value 380 (3.8 V) is returned.

5.6 Change Time Out CT

This command defines the input character timeout.

Input syntax: CT<value><EOT>
 Output syntax: *<EOT>
 Parameters: <value> = 001-250 (steps of 0.1 seconds)

If this command has not been received, the default timeout of 10 seconds applies.

The new timeout will be activated within 500 ms after command is received.

The timeout is shared between Basic and Extended mode, e.g. if the timeout is changed in basic mode, the new value is applicable in both basic and extended mode.

When receiving a command, CIE needs to receive any character within the set time-out. Otherwise the previous characters will be ignored.

5.7 Define Breath DB

This command defines which channels to be read by the instruction Read Breath. A minimum of 1 and a maximum of 32 channels can be defined. It is possible to choose an arbitrary number of channels in arbitrary row of order. The definition is valid until next time the command Define Breath is issued.

Input syntax: DB<n₁>[<n₂>...<n₃₂>]<EOT>
 Output syntax: *<EOT>
 Parameters: <n₁>...<n₃₂> = 00 – 39, channel number

The new channel table is activated within 500 ms after the response has been sent.

5.8 Define Curve DC

This command defines which channels to be read by the instruction Read Curve or Ultra Curve. A minimum of 1 and a maximum of 4 channels can be defined. It is possible to choose an arbitrary number of channels in arbitrary row of order. The definition is valid until next time the command Define Curve is issued.

Input syntax: DC<n₁>[<n₂>...<n₄>]<EOT>

Output syntax: *<EOT>

Parameters: <n₁>...<n₄> = 00 – 39, channel number

The new channel is activated within 500 ms after the variable has been set.

5.9 Firmware Version SV

This command requests information about the firmware version. The reason for this command is only to keep compatibility with the SCM 990, see ref. [2].

Input syntax: SV<EOT>

Output syntax: 002200<EOT>

5.10 Hello HO

This command is a general call from the external equipment to the CIE to check the connection. The reason for this command is only to keep compatibility with the SCM 990, see ref. [2].

Input syntax: HO<EOT>

Output syntax: 900PCI<EOT>

Please see section 4.5 for further details about this command.

5.11 Read Breath RB

This command reads the channels defined by the command Define Breath. The read channel information always comes from the last completed breath cycle.

Input syntax: RB<EOT>

Output syntax: <value₍₀₎>...<value_(n)><EOT>

Parameters: <value₍₀₎>...<value_(n)> = 0000 – 9999

n = 0 – 31

When SERVO-i / SERVO-s is in standby mode, this command returns ER10, i.e. it is not a valid command in standby mode.

5.12 Read Curve RC

This command reads the channels defined by the command Define Curve. When CIE receives this command, it waits until the given trigger condition <trigger_point> is true, e.g. start of inspiration. Then CIE samples the defined curve channels and returns the result periodically until the requested number of samples are returned. The sampling period is defined by the command Change Sampling Time.

Input syntax: RC<n>[<trigger_point>]<EOT>

Output syntax: <time_phase>[<value_(1,1)><value_(2,1)><value_(3,1)><value_(4,1)>]...

<time_phase>[<value_(1,n)><value_(2,n)><value_(3,n)><value_(4,n)>]<EOT>

Parameters:

n = 0001 – 1500, number of samples

<trigger_point> = { 0 (free run),
 1 (start insp), (default)
 2 (end insp),
 3 (start exp),
 4 (end exp)}

<time_phase> = { I (insp time),
 P (pause time),
 E (exp time)}

<value_(1,1)>...<value_(4,n)> = 0000 – 9999

During Nasal CPAP:

<trigger_point> ignored and treated as 0 (free run)

<time_phase> will always be E (exp time)

The maximum time difference between transmitted value and sampled value is less than 500 ms.

When SERVO-i / SERVO-s is in standby mode, this command returns ER10, i.e. it is not a valid command in standby mode.

If SERVO-i / SERVO-s is set in standby mode before the <trigger_point> is reached, this command returns ER10.

5.13 Read Sampling Time RS

This command reads the set sampling time (in milliseconds). See further the command [Change Sampling Time](#).

Input syntax:	RS<EOT>
Output syntax:	<value><EOT>
Parameters:	<value> = 010 – 224 (ms)

5.14 Read Time RT

This command reads the Real Time Clock.

Input syntax:	RT<EOT>												
Output syntax:	<year><month><day><hour><minute><sec><EOT>												
Parameters:	<table><tr><td><year></td><td>= 00 – 99</td></tr><tr><td><month></td><td>= 01 – 12</td></tr><tr><td><day></td><td>= 01 – 31</td></tr><tr><td><hour></td><td>= 00 – 23</td></tr><tr><td><minute></td><td>= 00 – 59</td></tr><tr><td><sec></td><td>= 00 – 59</td></tr></table>	<year>	= 00 – 99	<month>	= 01 – 12	<day>	= 01 – 31	<hour>	= 00 – 23	<minute>	= 00 – 59	<sec>	= 00 – 59
<year>	= 00 – 99												
<month>	= 01 – 12												
<day>	= 01 – 31												
<hour>	= 00 – 23												
<minute>	= 00 – 59												
<sec>	= 00 – 59												

5.15 Read Version RV

This command reads the ventilator product name.

Input syntax:	RV<EOT>
Output syntax:	
SERVO-i	Servo-i<EOT>
SERVO-s	Servo-s<EOT>

5.16 Change Sampling Time CS

This command sets the sampling time (in milliseconds). The default sampling time is 20 ms. Only one sampling time can be set at a time to be valid for all sampled channels until next time the command Change Sampling Time is received.

Input syntax: CS<value><EOT>

Output syntax: *<EOT>

Parameters: <value> = 004 – 224 (ms)

Odd requested sampling time is decremented by 1 ms.

The new sampling time is activated within 500 ms.

The new sampling time is shared between Basic and Extended mode, e.g. if the sampling time is changed in extended mode, the new value is applicable in both basic and extended mode.

Furthermore the sampling time is persistent, i.e. it is stored in persistent memory between ventilator sessions.

The minimum internal sampling time is 10 ms. In cases where the requested sampling time is less than 10 ms, it is set to 10 ms.

5.17 Set Time ST (not supported)

This command is supposed to set the Real Time Clock. *It is not supported anymore since it affects the existing trend data.*

Input syntax: ST<year><month><day><hour><minute><EOT>

Output syntax: ER10<EOT>

Parameters:

<year>	= 00 – 99
<month>	= 01 – 12
<day>	= 01 – 31
<hour>	= 00 – 23
<minute>	= 00 – 59

5.18 Trend Output TO

This command reads one of the trend channels from the trend memory, the last value is presented first.

Input syntax: TO<k>[<start_time>]<length><EOT>

Output syntax:

SERVO-i / SERVO-s <t_{0(0)(-1)[;<t_{1(-x)(-n+1)}}

SERVO-s of
System version 1.0 ER15<EOT>
No trend data is available in SERVO-s v1.0

Parameters:	<k>	= 00 – 33, trend channel number
	<year>	= 00 – 99
	<month>	= 01 – 12
	<day>	= 01 – 31
	<hour>	= 00 – 23
	<minute>	= 00 – 59
	<sec>	= 00 – 59
	<start_time>	= <year><month><day><hour><min><sec>
	<length>	= <hour><min><sec>
	<t ₀₁ >	= <year><month><day><hour><min><sec>
	<value ₍₀₎ >...<value _(-n + 1) >	= 0000 – 9999

If no <start_time> is selected, the default <start_time> will be the time of the last trend value.

The first time stamp <t₀> of the response is mandatory, in case there are any trend values to return.

Subsequent time stamps <t₁> are given in case of discontinuities in the trend, e.g. if the SERVO-i has been turned off for a while.

5.19 Ultra Curve UC

This command reads the values, in compressed binary format, of the channels defined by the command Define Curve. When CIE receives this command, it waits until the given trigger condition <trigger_point> is true, e.g. start of inspiration. Then CIE samples the defined curve channels and returns the result periodically until the requested number of samples are returned. The sampling period is defined by the command Change Sampling Time.

Input syntax: UC<n>[<trigger_point>]<EOT>

Normal Output syntax: <phase_flag><phase>[<value_flag><value_(1,1)>
 <value_flag><value_(2,1)><value_flag><value_(3,1)>
 <value_flag><value_(4,1)>][<diff_value_(1,2)>
 <diff_value_(2,2)><diff_value_(3,2)><diff_value_(4,2)>]...
 <phase_flag><phase>[<diff_value_(1,x)><diff_value_(2,x)>
 <diff_value_(3,x)><diff_value_(4,x)>]...
 [<value_flag><value_(1,y)><diff_value_(2,y)><diff_value_(3,y)>
 <diff_value_(4,y)>]...
 [<diff_value_(1,n)><diff_value_(2,n)><diff_value_(3,n)>
 <diff_value_(4,n)>]
 <end_flag>

Output syntax in case of error: <error_flag><error><end_flag>

Parameters: $n = 0001 - 1500$ (number of samples, ASCII)

$\langle \text{trigger_point} \rangle = \{$

- 0 (free run, ASCII),
- 1 (start insp, ASCII) – default
- 2 (end insp, ASCII),
- 3 (start exp, ASCII),
- 4 (end exp, ASCII)}

$\langle \text{phase_flag} \rangle = 81_{16}$

$\langle \text{phase} \rangle = \{$

- 10_{16} (insp time),
- 20_{16} (pause time),
- 30_{16} (exp time)}

$\langle \text{error_flag} \rangle = E0_{16}$

$\langle \text{error} \rangle = XX_{16}$ (binary error code)

$\langle \text{value_flag} \rangle = 80_{16}$

$\langle \text{value}_{(1,1)} \rangle \dots \langle \text{value}_{(4,n)} \rangle = 0000_{16} - 7EFF_{16}$ (MSB first)

$\langle \text{diff_value}_{(1,2)} \rangle \dots \langle \text{diff_value}_{(4,n)} \rangle = 82_{16} - 7E_{16}$

$(82_{16} = -126_{10}; 7E_{16} = 126_{10})$

$\langle \text{end_flag} \rangle = 7F_{16}$

During Nasal CPAP:

$\langle \text{trigger_point} \rangle$ ignored and treated as 0 (free run)

$\langle \text{phase} \rangle$ will always be 30_{16} (exp time)

The CIE transmits the channel values according to the channel table set up by the command Define Curve. The CIE responds to the command within 500 ms after the $\langle \text{trigger_point} \rangle$. The maximum time difference between transmitted value and sampled value is less than 500 ms.

Values are sent as differences $\langle \text{diff_value} \rangle$ when possible in order to save bandwidth, where $\langle \text{diff_value} \rangle$ is the difference between the current and the preceding value, i.e. $\langle \text{diff_value} \rangle = \langle \text{value}_{(t)} \rangle - \langle \text{value}_{(t-1)} \rangle$.

Absolute values $\langle \text{value} \rangle$ are sent the first time and when the difference is too large. An absolute value will be preceded by a value flag $\langle \text{value_flag} \rangle$. The most significant byte (MSB) of an absolute value is sent first.

The breath phase $\langle \text{phase} \rangle$ is sent the first time and then only upon breath phase changes. It is preceded by a phase flag $\langle \text{phase_flag} \rangle$.

When SERVO-i / SERVO-s is in standby mode this command returns ER10, i.e. it is not a valid command in standby mode.

If SERVO-i / SERVO-s is set in standby mode before the $\langle \text{trigger_point} \rangle$ is reached, this command returns ER10.

5.20 Ultra Trend UT

This command reads one of the trend channels from the trend memory, the last value is presented first. Compressed binary coded format is used (8 data bits).

Input syntax: UT<k>[<start_time>]<length><EOT>
 SERVO-i / SERVO-s <time_flag><t₀><value_flag><value₍₀₎><diff_value₍₋₁₎>...
 Normal output syntax: <time_flag><t₁><diff_value_(-x)>...<value_flag><value_(-y)>...
 <diff_value_(-n+1)><end_flag>

SERVO-i / SERVO-s <error_flag><error><end_flag>
 Output syntax in case of error:

SERVO-s of System E00F7F
 version 1.0 No trend data is available in SERVO-s v1.0
 Output syntax:

Parameters: <k> = 00 – 33 (trend channel, ASCII)
 <year> = 00 – 99
 <month> = 01 – 12
 <day> = 01 – 31
 <hour> = 00 – 23
 <minute> = 00 – 59
 <sec> = 00 – 59
 <start_time> = <year><month><day><hour><min><sec> (ASCII)
 <length> = <hour><min><sec> (ASCII)
 <error_flag> = E0₁₆
 <error> = XX₁₆(binary error code)
 <time_flag> = 81₁₆
 <t₀₁> = <year><month><day><hour><min><sec> (binary)
 <value_flag> = 80₁₆
 <value₍₀₎>...<value_(-n+1)> = 0000₁₆ – 7EFF₁₆(MSB first)
 <diff_value₍₋₁₎>...<diff_value_(-n+1)> = 82₁₆ – 7E₁₆
 (82₁₆ = -126₁₀ ; 7E₁₆ = 126₁₀)
 <end_flag> = 7F₁₆

If no <start_time> is selected, the default <start_time> will be the time of the last trend value.

The first time stamp <t₀> of the response is mandatory, in case there are any trend values to return.

Subsequent time stamps <t₁> are given in case of discontinuities in the trend, e.g. if the SERVO-i has been turned off for a while. A time stamp is preceded by a time flag <time_flag>.

Values are sent as differences <diff_value> when possible in order to save bandwidth, where <diff_value> is the difference between the current and the succeeding value, i.e. <diff_value> = <value_(t)> - <value_(t+1)>.

Absolute values <value> are sent the first time and when the difference is too large. An absolute value is preceded by a value flag <value_flag>. The most significant byte (MSB) of an absolute value is sent first.

6 Extended Commands

6.1 General

The EXTENDED commands below are according to the SV 300 CI, Version 2.0 and above (see ref. [1]).

Equipment administration commands:

Empty command	The empty command can be used for connection check.
Read Address Number, RADN	Reads the address number of the ventilator (emulated).
Read Analog Input Code, RAIC	Reads the status of the aux input, i.e. on or off, and aux. input code (emulated).
Read Battery, RBAT	Reads the internal battery voltage (emulated).
Read Channel Configuration, RCCO	Reads the channel configuration.
Read CI Type, RCTY	General call from the external equipment to the CIE to check the connection and to enter EXTENDED Mode.
Read Highest Protocol Version, RHVE	Requests information about the highest available CIE Protocol version for the current SW release.
Read Protocol Version, RPVE	Requests information about the CIE Protocol version currently in use.
Read Serial Number, RSEN	Reads the serial number of the ventilator.
Read Software Version, RSWV	Requests technical information about the SERVO Ventilator modules.
Read Text, RETX	Reads stored text strings.
Read Time, RTIM	Reads the Real Time Clock.
Read Time out, RTOU	Reads the command timeout.
Set Protocol Version, SPVE	Configures CIE to use a specific Protocol version.
Set Time, STIM	Sets the Real Time Clock (not supported).
Set Time Out, STOU	Defines the command timeout.
Store Text, STTX	Store text string.

Data acquisition commands:

Set Data Acquisition Definition, SDAD	Defines which channels to be read by the command Read Acquired Data.
Read Data Acquisition Definition, RDAD	Reads the Data Acquisition channel definition table defined by the instruction Set Data Acquisition Definition.
Read Acquired Data, RADA	Read data stream.
Read Acquired Data Continuously, RADC	Read combined data stream continuously.
Read Sampling Time, RSTI	Reads the sampling time in milliseconds.
Set Sampling Time, SSMP	Sets the sampling time in milliseconds.
Read Alarm Output, RALO	Requests alarm status.

Patient administration commands:

Admit Patient, ADMP	Stores the patient id with the time when the command was received. Optionally, a specific time may be entered (not supported).
Discharge Patient, DISP	Removes the patient id from the active patient field and stores the patient information, patient id, admittance time and discharge time in the patient history table (not supported).
Read Patient Info, RPAI	Reads the patient information from the active patient field. Optionally, the patient history table may be retrieved.

6.2 Empty command

CIE responds to the empty command in extended mode.

Input syntax:	<EOT>
Output syntax:	*<CHK><EOT>

6.3 Admit Patient ADMP

This command is not supported by CIE, and hence CIE returns ER10 if this command is received.

6.4 Discharge Patient DISP

This command is not supported by CIE, and hence CIE returns ER10 if this command is received.

6.5 Read Acquired Data RADA

This command reads the data, i.e. curve-, breath-, settings-, trend- or alarm data, according to the channel table setup via the command Set Data Acquisition Definition. Each type of RADA command is described in detail in the subsections below.

6.5.1 Curve Data

Input syntax:	RADA<curve_parameters><CHK><EOT>
Normal Output syntax:	<phase_flag><phase><value_flag><value_(1,1)> [<value_flag><value_(2,1)><value_flag><value_(3,1)> <value_flag><value_(4,1)>]<diff_value_(1,2)> [<diff_value_(2,2)><diff_value_(3,2)><diff_value_(4,2)>]... <phase_flag><phase><diff_value_(1,x)>[<diff_value_(2,x)> <diff_value_(3,x)><diff_value_(4,x)>]... <value_flag><value_(1,y)>[<diff_value_(2,y)><diff_value_(3,y)> <diff_value_(4,y)>]... <diff_value_(1,n)>[<diff_value_(2,n)><diff_value_(3,n)> <diff_value_(4,n)>] <end_flag><CHK>
Output syntax in case of error:	<error_flag><error><end_flag><CHK>

Parameters: $\langle \text{curve_parameters} \rangle = \text{UC}\langle n \rangle[\langle \text{trigger_point} \rangle][\langle \text{end_trigger_point} \rangle]$

$n = 0001 - 1500$ (number of samples, ASCII)

$\langle \text{trigger_point} \rangle = \{$
 0 (free run, ASCII),
 1 (start insp, ASCII) – default
 2 (end insp, ASCII),
 3 (start exp, ASCII),
 4 (end exp, ASCII) $\}$

$\langle \text{end_trigger_point} \rangle = \{$
 0 (free run, ASCII),
 1 (start insp, ASCII)
 2 (end insp, ASCII),
 3 (start exp, ASCII),
 4 (end exp, ASCII) $\}$

$\langle \text{phase_flag} \rangle = 81_{16}$

$\langle \text{phase} \rangle = \{$
 10_{16} (insp time),
 20_{16} (pause time),
 30_{16} (exp time) $\}$

$\langle \text{error_flag} \rangle = E0_{16}$

$\langle \text{error} \rangle = XX_{16}$ (binary error code)

$\langle \text{value_flag} \rangle = 80_{16}$

$\langle \text{value}_{(1,1)} \rangle \dots \langle \text{value}_{(4,n)} \rangle = 0000_{16} - 7EFF_{16}$ (MSB first)

$\langle \text{diff_value}_{(1,2)} \rangle \dots \langle \text{diff_value}_{(4,n)} \rangle = 82_{16} - 7E_{16}$

($82_{16} = -126_{10}$; $7E_{16} = 126_{10}$)

$\langle \text{end_flag} \rangle = 7F_{16}$

During Nasal CPAP:

$\langle \text{trigger_point} \rangle$ ignored and treated as 0 (free run)

$\langle \text{phase} \rangle$ will always be 30_{16} (exp time)

If no $\langle \text{trigger_point} \rangle$ selected, the default value 1 (start insp.) applies.

If no $\langle \text{end_trigger_point} \rangle$ selected, $\langle n \rangle$ samples will be transmitted.

If $\langle \text{end_trigger_point} \rangle$ selected, $\langle \text{trigger_point} \rangle$ must also be selected. In this case the command transmits samples until the trigger condition $\langle \text{end_trigger_point} \rangle$ is true or a maximum of $\langle n \rangle$ samples are transmitted.

Values are sent as differences $\langle \text{diff_value} \rangle$ when possible in order to save bandwidth, where $\langle \text{diff_value} \rangle$ is the difference between the current and the preceding value, i.e. $\langle \text{diff_value} \rangle = \langle \text{value}_{(t)} \rangle - \langle \text{value}_{(t-1)} \rangle$.

Absolute values $\langle \text{value} \rangle$ are sent the first time and when the difference is too large. An absolute value will be preceded by a value flag $\langle \text{value_flag} \rangle$. The most significant byte (MSB) of an absolute value is sent first.

The breath phase $\langle \text{phase} \rangle$ is sent the first time and then only upon breath phase changes. It is preceded by a phase flag $\langle \text{phase_flag} \rangle$.

Note that RADAUC in combination with the start trigger can result in delay of answer.

ESC command shall be used if RADAUC command shall be aborted before start trigger point is reached.

All other commands, except ESC, are ignored during execution of this command.

When SERVO-i / SERVO-s is in standby mode, this command returns the binary error code 17.

If no curve channels are defined, this command returns the binary error code 16.

If SERVO-i / SERVO-s is set in standby mode before the $\langle \text{trigger_point} \rangle$ is reached, this command returns the binary error code 17.

6.5.2 Breath Data

Input syntax: RADA< breath_parameters ><CHK><EOT>
 Output syntax: <value₍₀₎>...<value_(n)> <CHK><EOT>
 Parameters: <breath_parameters> = B
 <value₍₀₎>...<value_(n)> = 0000 – 9999
 n = 0 – 49

When SERVO-i / SERVO-s is in standby mode, this command returns ER17.

If no breath channels are defined, this command returns ER16.

The read channel information always comes from the last completed breath channel.

6.5.3 Settings Data

Input syntax: RADA<setting_parameters><CHK><EOT>
 Output syntax: <value₍₀₎>...<value_(n)><CHK><EOT>
 Parameters: <setting_parameters> = S
 <value₍₀₎>...<value_(n)> = 0000 – 9999
 n = 0 – 74

When SERVO-i / SERVO-s is in standby mode, this command returns ER17.

If no settings channels are defined, this command returns ER16.

6.5.4 Alarm Data

Input syntax: RADA<alarm_parameters><CHK><EOT>
 Output syntax: <alarm_value₍₀₎>...< alarm_value_(n)><CHK><EOT>
 Parameters: <alarm_parameters> = A
 <alarm_value₍₀₎>...< alarm_value_(n)> = { 0 (No Alarm)
 1 (Alarm)}
 n = 0 – 49

When SERVO-i / SERVO-s is in standby mode, this command returns ER17.

If no alarm channels are defined, or the alarm channels are defined with the SDADE command, this command returns ER16.

6.5.5 Alarm Data with extended output

Input syntax: RADA<alarm_parameters><CHK><EOT>
 Output syntax: <alarm_value₍₀₎>...< alarm_value_(n)><CHK><EOT>
 Parameters: <alarm_parameters> = E
 <alarm_value₍₀₎>...< alarm_value_(n)> = { 0 (No Alarm)
 1 (Alarm active)
 2 (Alarm active but silenced)}
 n = 0 – 49

When SERVO-i / SERVO-s is in standby mode, this command returns ER17.

If no alarm channels are defined, or the alarm channels are defined with the SDADA command, this command returns ER16.

6.5.6 Trend Data

The trend data can be retrieved in different formats—ASCII or binary, the table for them follows below.

ASCII format:

Input syntax: RADA<trend_parameters><CHK><EOT>

Output syntax
SERVO-i / SERVO-s

Breath Channels:
 $\langle t_0 \rangle, \langle \text{value}_{(0)} \rangle, \langle \text{value}_{(-1)} \rangle \dots$

$[\langle t_1 \rangle, \langle \text{value}_{(-x)} \rangle, \dots, \langle \text{value}_{(-n+1)} \rangle] \langle \text{CHK} \rangle \langle \text{EOT} \rangle$

Settings Channels: Not available

Alarm Channels: Not available

Output syntax
SERVO-s of System
version 1.0

ER15<CHK><EOT>

No trend data is available in SERVO-s v1.0.

Parameters:

$\langle \text{trend_parameters} \rangle = \text{AT} \langle \text{chan} \rangle [\langle \text{start_time} \rangle] \langle \text{length} \rangle$

$\langle \text{chan} \rangle = 200 - 499$, channel number

$\langle \text{start_time} \rangle = \langle \text{year} \rangle \langle \text{month} \rangle \langle \text{day} \rangle \langle \text{hour} \rangle \langle \text{min} \rangle \langle \text{sec} \rangle$

$\langle \text{length} \rangle = \langle \text{hour} \rangle \langle \text{min} \rangle \langle \text{sec} \rangle$

$\langle t_0 \rangle, \langle t_1 \rangle = \langle \text{year} \rangle \langle \text{month} \rangle \langle \text{day} \rangle \langle \text{hour} \rangle \langle \text{min} \rangle \langle \text{sec} \rangle$

$\langle \text{year} \rangle = 00 - 99$

$\langle \text{month} \rangle = 01 - 12$

$\langle \text{day} \rangle = 01 - 31$

$\langle \text{hour} \rangle = 00 - 23$

$\langle \text{minute} \rangle = 00 - 59$

$\langle \text{sec} \rangle = 00 - 59$

$\langle \text{value}_{(0)} \rangle \dots \langle \text{value}_{(-n+1)} \rangle = 0000 - 9999$

This command reads one of the trend channels from the trend memory; the last value is presented first.

If no $\langle \text{start_time} \rangle$ is selected, the default $\langle \text{start_time} \rangle$ will be the time of the last trend value.

The first time stamp $\langle t_0 \rangle$ of the response is mandatory in case there are any trend values to return.

Subsequent time stamps $\langle t_1 \rangle$ are given in case of discontinuities in the trend, e.g. if the SERVO-i has been turned off for a while.

Since no settings- or alarm trends are available, CIE returns ER15 if such a trend is requested.

Compressed binary coded format (8 data bits):

Input syntax: RADA<trend_parameters><CHK><EOT>

SERVO-i / SERVO-s Breath Channels:

Normal output
syntax: <time_flag><t₀><value_flag><value₍₀₎>
<diff_value₍₋₁₎>...<time_flag><t₁>
<diff_value_(-x)>...<value_flag>
<value_(-y)>...<diff_value_(-n+1)><end_flag><CHK>

Settings Channels: Not available

Alarm Channels: Not available

SERVO-i / SERVO-s <error_flag><error><end_flag><CHK>
Output syntax in
case of error:

SERVO-s of System E00F7F<CHK>
version 1.0 No trend data is available in SERVO-s v1.0.
Output syntax:

Parameters: <trend_parameters> = UT<chan>[<start_time>]<length>
<chan> = 200 – 499, channel number
<start_time> = <year><month><day><hour><min><sec>
<length> = <hour><min><sec>
<year> = 00 – 99
<month> = 01 – 12
<day> = 01 – 31
<hour> = 00 – 23
<minute> = 00 – 59
<sec> = 00 – 59
<error_flag> = E0₁₆
<error> = XX₁₆(binary error code)

<time_flag> = 81₁₆
<t₀>, <t₁> = <year><month><day><hour><min><sec>

<value_flag> = 80₁₆
<value₍₀₎>...<value_(-n+1)> = 0000₁₆ – 7EFF₁₆ (MSB first)

<diff_value₍₋₁₎>...<diff_value_(-n+1)> = 82₁₆ – 7E₁₆
(82₁₆ = -126₁₀; 7E₁₆ = 126₁₀)

<end_flag> = 7F₁₆

This command reads one of the trend channels from the trend memory; the last value is presented first.

If no <start_time> is selected, the default <start_time> will be the time of the last trend value.

The first time stamp $\langle t_0 \rangle$ of the response is mandatory in case there are any trend values to return. Subsequent time stamps $\langle t_1 \rangle$ are given in case of discontinuities in the trend, e.g. if the SERVO-i has been turned off for a while. A time stamp is preceded by a time flag $\langle \text{time_flag} \rangle$.

Values are sent as differences $\langle \text{diff_value} \rangle$ when possible in order to save bandwidth, where $\langle \text{diff_value} \rangle$ is the difference between the current and the succeeding value, i.e. $\langle \text{diff_value} \rangle = \langle \text{value}_{(t)} \rangle - \langle \text{value}_{(t+1)} \rangle$.

Absolute values $\langle \text{value} \rangle$ are sent the first time and when the difference is too large. An absolute value will be preceded by a value flag $\langle \text{value_flag} \rangle$. The most significant byte (MSB) of an absolute value is sent first.

Since no settings or alarm trends are available, CIE returns the binary error code 15 if such a trend is requested.

6.6 Read Acquired Data Continuously RADC

This command reads the data continuously, i.e. curve-, breath-, settings-, trend- or alarm data according to the channel table set-up via the command Set Data Acquisition Definition.

It is possible to read 1 or more curves at the same time. Up to 4 curves are allowed.

New breath data is transmitted when the breath is finished, i.e. when a new breath is started.

Breath/Setting/Alarm data package is transmitted when some of the data, according to the channel table set-up, is updated.

The curve data are transferred continuously. However, if an alarm occurs, a setting changes, new breath data are available or new one-minute trend are available, the curve data transfer will be temporarily interrupted.

If buffer overflow occurs, ESC is received or 'Standby' mode set, the transmission stops.

Input syntax:	RADC<CHK><EOT>
Normal Output syntax:	[<settings_data><CHK>] [<alarm_data><CHK> or <alarm_data_extended><CHK>] [<curve_data><CHK>] [<breath_data><CHK>] [<trend_data><CHK>]
Output syntax in case of error:	<error_flag><error><end_flag><CHK>
Scenario:	<settings_data><CHK><alarm_data><CHK><curve_data><CHK> <breath_data><CHK><trend_data><CHK>...

Parameters: <curve_data> =

 <phase_flag><phase><value_flag><value_(1,1)>

 [<value_flag><value_(2,1)><value_flag><value_(3,1)>

 <value_flag><value_(4,1)>]<diff_value_(1,2)>

 [<diff_value_(2,2)><diff_value_(3,2)><diff_value_(4,2)>]...

 <phase_flag><phase><diff_value_(1,x)> [<diff_value_(2,x)>

 <diff_value_(3,x)><diff_value_(4,x)>]...

 <value_flag><value_(1,y)> [<diff_value_(2,y)><diff_value_(3,y)>

 <diff_value_(4,y)>]...

 <diff_value_(1,n)> [<diff_value_(2,n)><diff_value_(3,n)>

 <diff_value_(4,n)>]

 <end_flag>

 <error_flag> = E0₁₆

 <error> = XX₁₆(binary error code)

 <phase_flag> = 81₁₆

 <phase> = { 10₁₆ (insp time),

 20₁₆ (pause time),

 30₁₆ (exp time)}

 <value_flag> = 80₁₆

 <value_(1,1)>...<value_(4,n)> = 0000₁₆ – 7EFF₁₆ (MSB first)

 <diff_value_(1,2)>...<diff_value_(4,n)> = 82₁₆ – 7E₁₆

 (82₁₆ = -126₁₀ ; 7E₁₆ = 126₁₀)

 <end_flag> = 7F₁₆

 n = 0 - ∞

 <alarm_data> =

 A<value₍₀₎>...<value_(n)><end_flag>

 <value₍₀₎>...<value_(n)> = { 00₁₆ (No Alarm)

 FF₁₆ (Alarm)}

 n = 0 - 49

`<alarm_data_extended> =`
`E<value(0)>...<value(n)><end_flag>`
`<value(0)>...<value(n)> = {      0016 (No Alarm)`
`0116 (Alarm)`
`0216 (Alarm active but silenced)}`

`n = 0 - 49`

`<breath_data> =`
`B<value(0)>...<value(n)><end_flag>`
`<value(0)>...<value(n)> = 000016 – 7EFF16 (MSB first)`

`n = 0 – 49`

`<trend_data>`
 Breath Channels only:
`T[<time_flag><t0>]`
`<value(0)>...<value(n)><end_flag>`

`n = 0 – 49`
`<t0> = <year><month><day><hour><min><sec>`

`<value(0)>...<value(n)> = 000016 – 7EFF16 (MSB first)`

`<time_flag>      = 8116`
 The [`<time_flag><t0>`] shall be transmitted in the first trend data transmission block.

`<settings_data> =`

`S<value(0)>...<value(n)><end_flag>`
`<value(0)>...<value(n)> = 000016 – 7EFF16 (MSB first)`

`n = 0 – 74`
 During Nasal CPAP `<phase>` will always be 30₁₆ (exp time)

The CIE transmits channel data according to the channel table setup via Set Data Acquisition Definition command.

The maximum time difference between transmitted value and sampled value is less than 500 ms.

The `<end_flag>` is transmitted when curve data transfer is interrupted. The curve data transfer continues, after an interrupt, from where it was interrupted. When curve data transfer continues, absolute values are sent first.

Buffer Overflow or 'Standby' mode set: ...`<end_flag><CHK><end_flag>`

All other commands, except ESC, are ignored during execution of this command.

When SERVO-i / SERVO-s is in standby mode, this command returns the binary error code 17.

If no curve channels are defined, this command returns the binary error code 16.

6.7 Read Address Number RADN

The CIE returns the address number of the SERVO ventilator unit (emulated).

Input syntax: RADN[/<switch>]<CHK><EOT>
 Output syntax: <n><CHK><EOT>
 Emulated Output: 00<CHK><EOT>
 Parameters: <switch> = { /1 = Read current address number setup }
 <n> = 00-99

6.8 Read Alarm Output RALO

The CIE returns the summary alarm status.

Input syntax: RALO<CHK><EOT>
 Output syntax: <value><CHK><EOT>
 Parameters: <value> = { 0 (No Alarm),
 1 (Alarm active),
 [2 (Alarm active but silenced)] } (Note 1)

When SERVO-i / SERVO-s is in standby mode, this command returns ER17.

Note 1: Parameter value 2 only if alarm channels with extended output is configured.

6.9 Read Analog Input Code RAIC

The CIE returns the status of the aux input (emulated).

Input syntax: RAIC<CHK><EOT>
 Output syntax: <value><CHK><EOT>
 Emulated output: 255<CHK><EOT>
 Parameters: <value> = 001 – 255

The code 255 means that no device is connected.

A code in the range 128 to 254 is interpreted as if there is a device connected which is in an OFF state.

6.10 Read Battery RBAT

The CIE returns the internal battery voltage (emulated).

Input syntax: RBAT<CHK><EOT>
 Output syntax: <status>,<value><CHK><EOT>
 Emulated Output: 0,380<CHK><EOT>
 Parameters: <status> = 1 Not OK, should be replaced
 0 OK
 <value> = 000 – 999 (steps of 10 mV)

Since CIE has not battery of its own within SERVO-i / SERVO-s, the emulated value 380 (3.8 V) will be returned.

6.11 Read Channel Configuration RCCO

This command reads the channel configuration, e.g. gain, offset, either for a specific channel or for all available channels.

Input syntax: `RCCO[<ch>]<CHK><EOT>`

Output syntax: `<sampling_time>;
<ch1[<ch2<chn`

Parameters:
`<ch>` = 100 – 499 , channel number
`<sampling_time>` = 004 – 224 (ms)(even numbers only)
`<ch1n = 100 – 499 , channel`

`<gain>` = `<X>E<Y>`
 Interpretation: Gain = $X * 10^Y$
`<X>` = -9999 to +9999 , 5 ASCII characters
`<Y>` = -127 to +127 , 4 ASCII characters

`< offset >` = `<X>E<Y>`
 Interpretation: Offset = $X * 10^Y$
`<X>` = -9999 to +9999 , 5 ASCII characters
`<Y>` = -127 to +127 , 4 ASCII characters

`<unit>` = 01 to 99, 2 ASCII characters

<code><unit></code>	Unit
01	ml
02	ml/s
03	ml/min
04	cmH ₂ O
05	ml/cmH ₂ O
06	breaths/min
07	%
08	l/min
09	cmH ₂ O/l/s
10	mmHg
11	kPa
12	mbar
13	mV
14	s
15	l/s
16	cmH ₂ O/l
17	l
18	Joule/l
19	μV
20	no unit
21	cmH ₂ O/μV
22	breaths/min/l
23	min

6.14 Read Highest Protocol Version RHVE

This command requests information about the highest available CIE Protocol version for the current CIE SW.

Input syntax: RHVE<CHK><EOT>

Output syntax: <highest_version><CHK><EOT>

Parameters: <highest_version> = 003 (CIE Protocol version introduced with
SERVO-i / SERVO-s System version 6.0.)

<highest_version> = Highest available CIE Protocol version.

6.15 Read Patient Info RPAI

This command reads the patient information from the active patient field. Optionally, the patient history table may be retrieved.

Input syntax: RPAI[<history>]<CHK><EOT>

Output syntax: If history flag is not present in the command:
<id><admittance_time><CHK><EOT>

If history flag is present in the command:
<id₁><admittance_time₁><discharge_time₁>...
<id_n><admittance_time_n><discharge_time_n><CHK><EOT>

Emulated output: If history flag is present in the command a string of 30 ASCII '-' characters will be transmitted.

Parameters: <history> = H (ASCII)

<id> = Patient id, 20 ASCII characters

<admittance_time> = <year><month><day><hour><minute>

<discharge_time> = <year><month><day><hour><minute>

<year> = 00 – 99

<month> = 01 – 12

<day> = 01 – 31

<hour> = 00 – 23

<minute> = 00 – 59

The CIE responds to the command by transmitting the active patient information, i.e. the active patient ID and the admittance time.

A string of 30 ASCII '-' characters will be transmitted if no active patient exists.

CIE returns 00 for <hour> and <minute>, since SERVO-i / SERVO-s do not store any admittance/discharge time information, only date.

6.16 Read Protocol Version RPVE

This command requests information about the CIE Protocol version in use.

Input syntax: RPVE<CHK><EOT>

Output syntax: <current_version><CHK><EOT>

Parameters: <current_version> = 001 – xxx
 <current_version> = CIE Protocol version currently used. Set to 001 (introduced with SERVO-i / SERVO-s System version 4.0) as default.

The protocol version is selected with the command SPVE.

The protocol version is set to 001 when CIE enters EXTENDED Mode.

See section 4.5 for further details.

6.17 Read Serial Number RSEN

This command reads the serial number of the ventilator.

Input syntax: RSEN<CHK><EOT>

Output syntax: <serial_number><CHK><EOT>

Parameters: <serial_number> = ASCII character string containing serial number.

Output syntax in case of missing serial number: 0<CHK><EOT>

6.18 Read Sampling Time RSTI

This command reads the set sampling time (in milliseconds). See further the command Set Sampling Time.

Input syntax: RSTI<CHK><EOT>

Output syntax: <value><CHK><EOT>

Parameters: <value> = 010 – 224 (ms)

6.19 Read Software Version RSWV

This command requests information about the module firmware versions, PROM checksums, language as well as module configuration and error count.

Input syntax: RSWV[<switch>]<CHK><EOT>

Output syntax:

SERVO-i Servo-i,<lang>,<opt₁>,<opt₂>;
 <module_id₁>,<version>,<checksum>,<date>,<error_code>,<error_date>
 [,<com_error>,<timeout>];
 ...
 <module_id_n>,<version>,<checksum>,<date>,<error_code>,<error_date>
 [,<com_error>,<timeout>];<CHK><EOT>

SERVO-s

```
Servo-s,<lang>,<opt1>,<opt2>;
<module_id1>,<version>,<checksum>,<date>,
<error_code>,<error_date>
[,<com_error>,<timeout>];
...
<module_idn>,<version>,<checksum>,<date>
,<error_code>,<error_date>
[,<com_error>,<timeout>];<CHK><EOT>
```

Parameters:

```
<switch> = { /C = Clear error counters (Ignored)
              /E = Display internal communication error counters}

<lang> = selected language, 3 ASCII characters, see channel 329 for
         further details

<opt1> = '-', Not applicable
<opt2> = 001, CI hardware version – 3 ASCII characters

<module_id1>...<module_idn> = module id =
    { 001 (Breathing system),
      002 (Monitoring),
      003 (Not supported),
      004 (Panel),
      005 (ExpFlowMeter),
      006 (Computer Interface Emulator)
    }

<version> = Module PROM version, ASCII character string of
             length 30.

<checksum> = Not implemented in current SERVO-i / SERVO-s,
             Module PROM checksum, ASCII character string.
             The ASCII character '-' is returned.

<date> = Not implemented in current SERVO-i / SERVO-s,
          Module PROM code date checksum, ASCII
          character string. The ASCII character '-' is returned.

<com_error> = 000, Emulated reply because such information
              cannot be retrieved from the CAN controller. In the
              original CI, a counter was incremented when an
              internal communication error occurred. When the
              counter reached 255 it was not further updated. The
              <com_error> field could be 000 – 255.
```

<timeout> = 000, Emulated reply because such information cannot be retrieved from the CAN controller. In the original CI, a counter was incremented when an internal communication timeout occurred. When the counter reached 255 it was not further updated. The <timeout> field could be 000 – 255.

<error_code> = 00000 – 99999. Emulated {00000} because the information is not available in SERVO-i / SERVO-s.

<error_date> = {YYYYMMDDHHMMSS}, date that last error occurred. A string of 14 ASCII '-' characters will be transmitted because the information is not available in SERVO-i / SERVO-s.

The ASCII character '-' represents information not applicable or available.

6.20 Read Text RETX

The CIE responds to the command by transmitting the text string from the battery backedup wraparound buffer of at least 1600 characters. This command may be transmitted from a terminal and no checksum is used.

Input syntax: RETX<EOT>
 Output syntax: <text><EOT>
 Parameters: <text> = 0 – 1600 characters

6.21 Read Time RTIM

This command reads the Real Time Clock.

Input syntax: RTIM<CHK><EOT>
 Output syntax: <year><month><day><hour><minute><sec><CHK><EOT>
 Parameters:

<year>	= 00 – 99
<month>	= 01 – 12
<day>	= 01 – 31
<hour>	= 00 – 23
<minute>	= 00 – 59
<sec>	= 00 – 59

6.22 Read Time out RTOU

The CIE returns the set character timeout.

Input syntax: RTOU<CHK><EOT>
 Output syntax: <value><CHK><EOT>
 Parameters: <value> = 001 – 250 (steps of 0.1 seconds).

When receiving a command, CIE needs to receive any character within the set time-out. Otherwise the previous characters will be ignored.

6.23 Set Data Acquisition Definition SDAD

This command defines which channels to be read by the instruction Read Acquired Data or Read Acquired Data Continuously. The channels may contain curve, breath, trend, settings and alarm data.

Input syntax: SDADC[<n_{C1}>...<n_{C4}>]<CHK><EOT> or
 SDADB[<n_{B1}>...<n_{B50}>]<CHK><EOT> or
 SDADT[<n_{T1}>...<n_{T50}>]<CHK><EOT> or
 SDADS[<n_{S1}>...<n_{S75}>]<CHK><EOT> or
 SDADA[<n_{A1}>...<n_{A50}>]<CHK><EOT> or
 SDADE[<n_{A1}>...<n_{A50}>]<CHK><EOT>

Output syntax: *<CHK><EOT>

Parameters: [<n_{C1}>...<n_{C4}>] = 100 – 199 , curve channel number
 [<n_{B1}>...<n_{B50}>] = 200 – 299 , breath channel number
 [<n_{T1}>...<n_{T50}>] = 200 – 299 , trend channel number
 [<n_{S1}>...<n_{S75}>] = 300 – 399 , settings channel number
 [<n_{A1}>...<n_{A50}>] = 400 – 499 , alarm channel number

The CIE shall set up a Data acquisition table in memory of channels to be read by the RADA and RADC command. The max number of curve channels that can be set is 4. For breath, trend, settings and alarm data, the max number of channels is 50 for each category. The definition shall be valid until next time the command Set Data Acquisition Definition is issued.

If no channel parameters are given, the corresponding data acquisition table is cleared.

If the command Set Protocol Version (SPVE) is issued, or if CIE enters BASIC Mode, the data acquisition table will be cleared.

If alarm channels are set up with the command SDADA, any channels previously set up with SDADE are cleared and vice versa.

The new channel table will be activated within 500 ms after the variable has been set.

6.24 Set Protocol Version SPVE

This command configures CIE to use a specific protocol version.

Input syntax: SPVE<version><CHK><EOT>

Output syntax: *<CHK><EOT>

Parameters: <version> = 001 – xxx
 <version> = Selected CIE Protocol version. Selectable from first version (001) to highest (read by the RHVE command).

The requested version will be expressed with 3 digits; otherwise this command will return ER11.

When the Set Protocol Version command is issued the data acquisition table (set up with the Set Data Acquisition Definition command) will be cleared.

If the requested protocol version is not available this command will return ER12 and the ventilator will continue using the same protocol version and data acquisition definition as before the request.

6.25 Set Sampling Time SSMP

This command sets the sampling time in milliseconds. The default sampling time is 20 ms. Only one sampling time can be set at a time and this is valid for all sampled channels until next time the command Change Sampling Time is received.

Input syntax: SSMP<value><CHK><EOT>

Output syntax: *<CHK><EOT>

Parameters: <value> = 004 – 224 (ms)

Odd requested sampling time is decremented by 1 ms.

The new sampling time is activated within 500 ms.

The new sampling time is shared between Basic and Extended mode, e.g. if the sampling time is changed in extended mode, the new value is applicable in both basic and extended mode.

Furthermore the sampling time is persistent, i.e. it is stored in persistent memory between ventilator sessions.

The minimum internal sampling time is 10 ms. In cases where the requested sampling time is less than 10 ms, it is set to 10 ms.

6.26 Set Time STIM (not supported)

This command is supposed to set the Real Time Clock. *It is however not supported since it affects the existing trend data.*

Input syntax: STIM<year><month><day><hour><minute><CHK><EOT>

Output syntax: ER10<CHK><EOT>

Parameters:

<year>	= 00 – 99
<month>	= 01 – 12
<day>	= 01 – 31
<hour>	= 00 – 23
<minute>	= 00 – 59

6.27 Set Time Out STOU

This command defines the input character timeout.

Input syntax: STOU<value><CHK><EOT>

Output syntax: *<CHK><EOT>

Parameters: <value> = 001-250 (steps of 0.1 seconds)

If this command has not been received, the default timeout of 10 seconds applies.

The new timeout will be activated within 500 ms after command received.

The timeout is shared between Basic and Extended mode, e.g. if the timeout is changed in extended mode, the new value is applicable in both basic and extended mode.

When receiving a command, CIE needs to receive any character within the set time-out. Otherwise the previous characters will be ignored.

6.28 Store Text STTX

This command stores a text string in a battery backedup memory wrap-around buffer. This command may be transmitted from a terminal and no checksum is used.

Input syntax: STTX<text><EOT>

Output syntax: *<EOT>

Parameters: <text> = 0 – 80 ASCII characters

The CIE responds to the command by storing the text string appended with <CR><LF> in a wraparound buffer of at least 1600 characters.

7 Checksum Calculation

7.1 General

A checksum byte is included in transmission messages while in EXTENDED mode. The checksum is based on the exclusive OR operation (XOR).

7.2 Formula

The checksum is calculated according to the following formula:

Data:

Chk: Checksum byte

Number_Of_Bytes: Number of bytes in the message

$\wedge$: Bitwise XOR (exclusive OR)

Formula:

```
Chk = 0;
for ( i = 0; i < Number_Of_Bytes; i++ )
{
    Chk = Chk  $\wedge$  Message_Byte[i];
}
```

7.3 Checksum transmission

If Message format is ASCII, the checksum byte will be transmitted as two ASCII characters, representing the hexadecimal equivalent.

If Message format is Binary, the checksum byte will be transmitted as one byte.

7.4 Example

The command 'Read CI Type', RCTY will be transmitted:

RCTY1C<EOT>

Checksum byte = 1C₁₆

1C = ASCII equivalent

8 Revision History

8.1 Reference Manual – Revision 03

8.1.1 General changes – Revision 03

Information regarding the SERVO-s Computer Interface Emulator is added throughout the Reference Manual. These changes are not included in the Revision history table below.

8.1.2 History table – Revision 03

In the table below, the following keywords are used in 'Comment' column:

- Added. New functionality added with System version 2.0.
- Changed. Changed functionality e.g. due to System version 2.0.
- Corrected. Corrections made due to printing errors or lack of information in the previous version of the Reference Manual.

Page	Section	Comment
7	About SCM 990 compatibility	Information regarding sampling period changed.
7	About SV 300 compatibility	Information regarding sampling period changed.
8	4.3.1 Definitions	'NIV' added.
10-11	4.6 Error message handling	Error 'Buffer full' added.
11	4.6 Error message handling, Binary commands	BASIC and EXTENDED commands error messages corrected.
12-13	4.8.1 Channel 00-99	Channels 26-28 and 31 changed.
13	4.8.2 Channel 100-199	Channel 103 corrected.
13	4.8.2 Channel 100-199	Channels 113-114 added.
14	4.8.3 Channel 200-299	Channel 225 corrected.
14-15	4.8.3 Channel 200-299	Channels 229-236 and 238-252 added.
16	4.8.4 Channel 300-399	Channel 305 corrected.
17	4.8.4 Channel 300-399	Channels 333-356 added.
18	4.8.5 Switch Parameters for channels 300 to 399	Heading corrected.
18	4.8.5 Switch Parameters for channels 300 to 399	Switch parameters for channel 310 added.
20-21	4.8.5 Switch Parameters for channels 300 to 399	Channels 337, 349 and 351 added.
21-22	4.8.6 Channel 400-499	Channels 430-437 added.
26	5.9 Firmware Version SV	Output syntax changed.
27	5.13 Read Sampling Time RS	Information regarding sampling time and parameter values changed.
28	5.16 Change Sampling Time CS	Information regarding sampling time changed.
35	6.5.2 Breath Data	Information regarding read channel information corrected.
39	6.6 Read Acquired Data Continuously RADC	Normal output syntax and Scenario corrected.
43	6.11 Read Channel Configuration RCCO	Parameters for Units 14-18 added.
45	6.15 Read Sampling Time RSTI	Information regarding sampling time and parameter values changed.
48	6.20 Set Data Acquisition Definition SDAD	Information regarding Data acquisition table corrected.
49	6.21 Set Sampling Time SSMP	Information regarding sampling time changed.

8.2 Reference Manual – Revision 04

8.2.1 History table – Revision 04

In the table below, the following keywords are used in 'Comment' column:

- Added. New functionality added with System version 3.0.
- Changed. Changed functionality e.g. due to System version 3.0.
- Corrected. Corrections made due to printing errors or lack of information in the previous version of the Reference Manual.

Page	Section	Comment
10	4.5 Signal Handshake protocol	Information regarding computers with automatic Xon/Xoff control corrected.
10	4.6 Error handling	Error code ER12 corrected.
11	4.6 Error handling	Error code 0C16 corrected.
11	4.8.1 Channel 00-99	Information regarding Y-piece measurement added.
13	4.8.2 Channel 100-199	Information regarding Y-piece measurement added.
14	4.8.2 Channel 100-199	Channels 115-117 added.
14	4.8.3 Channel 200-299	Information regarding Y-piece measurement added.
15	4.8.3 Channel 200-299	Channels 253 and 254 added.
16	4.8.4 Channel 300-399	Channel 312 and 328 added.
17	4.8.4 Channel 300-399	Channel 356 changed.
17	4.8.4 Channel 300-399	Channel 357-360 added.
18	4.8.5 Switch Parameters for channels 300 to 399	Switch parameter for channel 310 added (Nasal CPAP).
21	4.8.5 Switch Parameters for channels 300 to 399	Switch parameters for channel 360 added.
22	4.8.6 Channel 400-499	Channels 438-440 added.
27	5.12 Read Curve RC	Information regarding Nasal CPAP added.
30	5.19 Ultra Curve UC	Information regarding Nasal CPAP added.
34	6.6 Read Acquired Data RADA	Information regarding Nasal CPAP added.
41	6.6 Read Acquired Data Continuously RADC	Information regarding Nasal CPAP added.

8.3 Reference Manual – Revision 05

8.3.1 History table – Revision 05

In the table below, the following keywords are used in 'Comment' column:

- Added. New functionality added with System version 3.2.
- Changed. Changed functionality e.g. due to System version 3.2.
- Corrected. Corrections made due to printing errors or lack of information in the previous version of the Reference Manual.

Page	Section	Comment
4	General information	Text changed due to System version 3.2.
4	Equipment combinations	Text corrected.
5	1 Introduction	Text changed due to System version 3.2
8	4.3.1 Definitions	Edi and NAVA added.
14	4.8.2 Channel 100-199	Channels 115-117 corrected.
14	4.8.2 Channel 100-199	Channel 118 added.
15	4.8.3 Channel 200-299	Channel 253 corrected.
15-16	4.8.3 Channel 200-299	Channels 255-258 added.
16	4.8.4 Channel 300-399	Channel 312 corrected.
17	4.8.4 Channel 300-399	Channels 358-359 corrected.
18	4.8.4 Channel 300-399	Channels 361-362 added.
19	4.8.5 Switch Parameters for channels 300 to 399	Switch parameters for channel 310 added (# 15 NAVA).
23	4.8.6 Channel 400-499	Channels 439-440 corrected.
23	4.8.6 Channel 400-499	Channels 441-443 added.
44	6.11 Read Channel Configuration RCCO	Unit parameters 19-21 added.

8.4 Reference Manual – Revision 06

8.4.1 History table – Revision 06

In the table below, the following keyword is used in 'Comment' column:

- Corrected. Corrections made due to lack of information in the previous version of the Reference Manual.

Page	Section	Comment
7	To consider when writing a CIE driver	Corrected: Text inserted.
21	Switch Parameters for channels No. 300 to 399	Corrected: Channel 330: Notes 1 and 2 inserted.
22	Switch Parameters for channels No. 300 to 399	Corrected: Notes 1 and 2 inserted.

8.5 Reference Manual – Revision 07

8.5.1 History table – Revision 07

In the table below, the following keywords are used in 'Comment' column:

- Added. New functionality added with System version 4.0.
- Changed. Changed functionality e.g. due to System version 4.0.
- Corrected. Corrections made due to printing errors or lack of information in the previous version of the Reference Manual.

Page	Section	Comment
4	General information	Text changed due to System version 4.0.
5	1. Introduction	Text changed due to System version 4.0.
7	About SV 300 compatibility	Corrected: Number of commands with emulated response.
8	4.3.1 Definitions	Added: Extended Alarm.
9	4.3.3 Common acronyms	Corrected: AT and ST deleted (not available).
11-12	4.6 Error handling	Corrected: Error descriptions in tables and table notes.
14	4.8.2 Channel 100-199	Corrected: % in channel 103.
15	4.8.2 Channel 100-199	Added: Channel 119.
16	4.8.3 Channel 200-299	Corrected: % in channel 225.
16	4.8.3 Channel 200-299	Changed: Note 4 in channel 246.
17	4.8.3 Channel 200-299	Added: Channels 259 – 260.
17	4.8.4 Channel 300-399	Changed: Note 4 in channels 313 and 314.
17	4.8.4 Channel 300-399	Corrected: % in channels 316 and 317.
18	4.8.4 Channel 300-399	Corrected: Parameter name on channel 322.
18	4.8.4 Channel 300-399	Changed: Channel 330 activated.
19	4.8.4 Channel 300-399	Added: Channels 363 – 367.
20-22	4.8.5 Switch Parameters for Channels 300-399	Corrected: Information in the table clarified.
22	4.8.5 Switch Parameters for Channels 300-399	Added: Channel 363.
24	4.8.6 Channel 400-499	Added: Channels 444 – 446.
25	4.8.6 Channel 400-499	Added: Alarm status information/tables.
28	5.12 Read Curve RC	Changed: Note regarding standby mode and trigger_point.
30	5.18 Trend Output TO	Corrected: SERVO-i / SERVO-s output syntax.
32	5.19 Ultra Curve RC	Changed: Note regarding standby mode and trigger_point.
36	6.5.1 Curve Data	Changed: Note regarding standby mode and trigger_point.
37	6.5.4 Alarm Data	Changed: Note regarding SDADE.
37	6.5.5 Alarm Data with extended output	Added: New RADA command.
38	6.5.6 Trend Data	Corrected: Breath Channels syntax.
38-40	6.5.6 Trend Data	Corrected: Settings and Alarm Channels syntax deleted (not available).
41	6.6 Read Acquired Data Continuously RADC	Corrected: Introduction clarified.
41	6.6 Read Acquired Data Continuously RADC	Added: Extended alarm data output syntax.
42	6.6 Read Acquired Data Continuously RADC	Added: Alarm data extended syntax.
44	6.8 Read Alarm Output RALO	Added: Parameters, value 2.

45	6.11 Read Channel Configuration RCCO	Added: Parameters, unit 22 (breaths/min/l).
46	6.11 Read Channel Configuration RCCO	Corrected: Parameters type AT and ST deleted (not available).
46	6.13 Read Data Acquisition Definition RDAD	Added: Extended alarm (E) output syntax.
50	6.17 Read Text RETX	Corrected: Parameters, 0 characters can be read.
50-51	6.20 Set Data Acquisition Definition SDAD	Added: SDADE (extended alarms) input syntax including note.
52	6.24 Store Text STTX	Corrected: Parameters, 0 characters can be stored. Note clarified.

8.6 Reference Manual – Revision 08

8.6.1 History table – Revision 08

In the table below, the following keywords are used in 'Comment' column:

- Added. New functionality added with System version 5.0.
- Changed. Changed functionality e.g. due to System version 5.0.
- Corrected. Corrections made due to printing errors or lack of information in the previous version of the Reference Manual.

Page	Section	Comment
4	General information	Text changed due to System version 5.0.
5	1. Introduction	Text changed due to System version 5.0.
7	About SV 300 compatibility	Corrected: Commands RADA and RADC included as modified.
7	About SV 300 compatibility	New commands added.
7	To consider when writing a CIE driver	Information changed.
9	Date format	Information corrected.
10	Signal Handshake protocol	Information regarding selection of CIE version added.
12	Support for different CIE protocol versions	Information regarding selection of CIE version added. Note: This new section will change chapter numbering within chapter 4 compared to previous versions of the Reference Manual.
17	4.9.3 Channel 200-299	Corrected: Note in channel 238.
17	4.9.3 Channel 200-299	Added: Channel 261 added for future application.
19	4.9.4 Channel 300-399	Corrected: Note in channel 333.
19	4.9.4 Channel 300-399	Changed: Channels 335 and 336 applicable also in invasive modes.
19	4.9.4 Channel 300-399	Corrected: Channels 341 and 342 applicable only in BIVENT.
19	4.9.4 Channel 300-399	Corrected: Channel 346 applicable only in SIMV modes.
19	4.9.4 Channel 300-399	Corrected: Note in channel 355.
20	4.9.4 Channel 300-399	Added: Channels 368 – 371.
21	4.9.5 Switch Parameters for Channels 300 to 399	Corrected: Channel 310, value 1 and 16 not used.
21	4.9.5 Switch Parameters for Channels 300 to 399	Added: Channel 310, value 17.
22	4.9.5 Switch Parameters for Channels 300 to 399	Added: Channel 329, new languages.
24	4.9.5 Switch Parameters for Channels 300 to 399	Added: Channel 371.
25	4.9.6 Channel 400-499	Corrected: Information in channels 411 and 414.
25	4.9.6 Channel 400-499	Changed: New alarms in channel 412.
26	4.9.6 Channel 400-499	Corrected: Information in channel 422.
26	4.9.6 Channel 400-499	Corrected: Channels 430 - 432 Parameter name adapted to information on the User Interface.
26	4.9.6 Channel 400-499	Added: Channels 447 – 450.
27	4.9.6 Channel 400-499	Added: Channels 451 – 452.
36	6.1 General	Added: Commands RHVE, RPVE, RSEN and SPVE.
38	6.5.1 Curve Data	Corrected: Information regarding RADAUC in combination with start trigger or ESC.

38	6.5.1 Curve Data	Changed: All other commands, except ESC, are ignored during execution of this command.
40-41	6.5.6 Trend Data	Corrected: Information regarding read-out order from trend memory.
44	6.6 Read Acquired Data Continuously RADC	Changed: All other commands, except ESC, are ignored during execution of this command.
47	6.12 Read CI Type RCTY	Corrected: Information regarding entering EXTENDED Mode.
48	6.14 Read Highest Protocol Version RHVE	Added: New command.
49	6.16 Read Protocol Version RPVE	Added: New command.
49	6.17 Read Serial Number RSEN	Added: New command.
52	6.23 Set Data Acquisition Definition SDAD	Changed: SPVE clears the acquisition table.
52	6.24 Set Protocol Version SPVE	Added: New command.

8.7 Protocol version 003 – Reference Manual revision 09

8.7.1 History table – Revision 09

In the table below, the following keywords are used:

- Added. New functionality added with Protocol version 003.
- Changed. Changed functionality with Protocol version 003
- Corrected. Corrections made due to printing errors or lack of information in the previous version of the Reference Manual.

Added	Changed	Corrected	Page	Section	Comment
		X	4-5	1. Introduction	This chapter is re-structured and adapted to similar information in other MAQUET documents.
		X	7	To consider when writing a CIE driver	The concept 'CIE Protocol version' introduced to identify different versions of the CIE protocol.
		X	13	4.7 Performance	Text information extended.
		X	13	4.8 Support for different CIE Protocol version	Clarification that new commands can be added in future protocol versions.
	X		18	4.9.3 Channel 200-299	Channel 238, gain changed.
X			18	4.9.3 Channel 200-299	Channels 261 and 262 introduced.
X			21	4.9.4 Channel 300-399	Channels 372 and 373 introduced.
X			25	4.9.5 Switch Parameters for Channels 300 to 399	Channel 372 introduced.
	X		40	6.5 Read Acquired Data RADA	Now possible to read 75 settings channels with RADAS.
		X	44	6.6 Read Acquired Data Continuously RADC	Clarification: possible to read 50 alarm channels.
		X	45	6.6 Read Acquired Data Continuously RADC	Clarification: possible to read 50 extended alarm channels.
	X		45	6.6 Read Acquired Data Continuously RADC	Now possible to read 75 settings channels.
X			47	6.11 Read Channel Configuration RCCO	Parameters; unit 23 min (minute) introduced.
	X		48	6.13 Read Data Acquisition Definition RDAD	Now possible with 75 settings channels.
	X		49	6.14 Read Highest Protocol Version RHVE	Highest Protocol version 003.
		X	49	6.14 Read Highest Protocol Version RHVE	The concept 'CIE Protocol version' used in Parameter description.
		X	50	6.16 Read Protocol Version RPVE	The concept 'CIE Protocol version' used in Parameter description.
	X		53	6.23 Set Data Acquisition Definition SDAD	Now possible to configure 75 settings channels.

Notes

[illegible]

MAQUET

GETINGE GROUP

Maquet Critical Care AB
Röntgenvägen 2
SE-171 54 Solna, Sweden
Phone: +46 8 730 73 00
www.maquet.com

For local contact:

Please visit our website
www.maquet.com

GETINGE GROUP is a leading global provider of products and systems that contribute to quality enhancement and cost efficiency within healthcare and life sciences. We operate under the three brands of ArjoHuntleigh, GETINGE and MAQUET. ArjoHuntleigh focuses on patient mobility and wound management solutions. GETINGE provides solutions for infection control within healthcare and contamination prevention within life sciences. MAQUET specializes in solutions, therapies and products for surgical interventions and intensive care.